



# **Automate Stack 3.1 Demo**

## **User Guide**

FPGA-UG-02207-1.1

February 2024

## Disclaimers

Lattice makes no warranty, representation, or guarantee regarding the accuracy of information contained in this document or the suitability of its products for any particular purpose. All information herein is provided AS IS, with all faults, and all associated risk is the responsibility entirely of the Buyer. The information provided herein is for informational purposes only and may contain technical inaccuracies or omissions, and may be otherwise rendered inaccurate for many reasons, and Lattice assumes no obligation to update or otherwise correct or revise this information. Products sold by Lattice have been subject to limited testing and it is the Buyer's responsibility to independently determine the suitability of any products and to test and verify the same. LATTICE PRODUCTS AND SERVICES ARE NOT DESIGNED, MANUFACTURED, OR TESTED FOR USE IN LIFE OR SAFETY CRITICAL SYSTEMS, HAZARDOUS ENVIRONMENTS, OR ANY OTHER ENVIRONMENTS REQUIRING FAIL-SAFE PERFORMANCE, INCLUDING ANY APPLICATION IN WHICH THE FAILURE OF THE PRODUCT OR SERVICE COULD LEAD TO DEATH, PERSONAL INJURY, SEVERE PROPERTY DAMAGE OR ENVIRONMENTAL HARM (COLLECTIVELY, "HIGH-RISK USES"). FURTHER, BUYER MUST TAKE PRUDENT STEPS TO PROTECT AGAINST PRODUCT AND SERVICE FAILURES, INCLUDING PROVIDING APPROPRIATE REDUNDANCIES, FAIL-SAFE FEATURES, AND/OR SHUT-DOWN MECHANISMS. LATTICE EXPRESSLY DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS OF THE PRODUCTS OR SERVICES FOR HIGH-RISK USES. The information provided in this document is proprietary to Lattice Semiconductor, and Lattice reserves the right to make any changes to the information in this document or to any products at any time without notice.

# Contents

|                                                                                   |    |
|-----------------------------------------------------------------------------------|----|
| Contents.....                                                                     | 3  |
| Acronyms in This Document .....                                                   | 9  |
| 1. Introduction .....                                                             | 10 |
| 2. Demo System Setup.....                                                         | 11 |
| 2.1. System Level Block Diagram.....                                              | 11 |
| 3. Communication Protocols (OPCUA) .....                                          | 12 |
| 3.1. Main System to Host PC Communication - OPCUA .....                           | 12 |
| 3.2. Main System to Node System Communication – OPCUA .....                       | 12 |
| 3.3. Node System to Node System Communication .....                               | 13 |
| 3.4. UDP Communication .....                                                      | 13 |
| 4. Hardware .....                                                                 | 14 |
| 4.1. Hardware Requirements .....                                                  | 14 |
| 4.2. Hardware Setup.....                                                          | 14 |
| 4.3. Hardware System Readiness .....                                              | 15 |
| 4.3.1. FPGA Board Programming.....                                                | 15 |
| 4.3.2. Power-up Sequence.....                                                     | 15 |
| 4.3.3. Status LEDs on Boards .....                                                | 15 |
| 5. Software Requirements .....                                                    | 17 |
| 5.1. Optional Software .....                                                      | 17 |
| 5.2. Software System Readiness .....                                              | 17 |
| 6. Automate Stack File Directory Structure .....                                  | 18 |
| 6.1. Executables.....                                                             | 18 |
| 6.1.1. Main System .....                                                          | 18 |
| 6.1.2. Node System.....                                                           | 18 |
| 6.2. User Interface.....                                                          | 18 |
| 7. Running the Motor through Automate User Interface Application (PC) .....       | 19 |
| 7.1. Starting the Application on Host PC .....                                    | 19 |
| 7.2. Connect to the Main System .....                                             | 20 |
| 7.3. Dashboard Tab .....                                                          | 22 |
| 7.4. Refresh Button .....                                                         | 22 |
| 7.5. Motor Configurations.....                                                    | 23 |
| 7.6. Target RPM, Voltage, and Drive Status Using the Dashboard Tab .....          | 27 |
| 7.7. Motor Status Test.....                                                       | 30 |
| 7.8. Forward/Reverse Rotation Test .....                                          | 32 |
| 7.9. PDM Data Collection .....                                                    | 34 |
| 7.9.1. Collect PDM Data.....                                                      | 34 |
| 7.9.2. Batch Mode .....                                                           | 37 |
| 7.9.3. Details about PDM Data Collection Process .....                            | 40 |
| 7.9.4. Collecting PDM Data from a Simulated Faulty Motor Using the Switches ..... | 41 |
| 7.10. Testing Node Peripherals .....                                              | 43 |
| 7.10.1. Making the Connection in Total Phase Control Center .....                 | 43 |
| 7.10.2. I <sup>2</sup> C .....                                                    | 46 |
| 7.10.3. SPI.....                                                                  | 48 |
| 7.10.4. Modbus.....                                                               | 49 |
| Appendix A. User Interface Application Installation (PC) .....                    | 52 |
| Appendix B. Programming the Automate Stack on Respective Flash.....               | 56 |
| B.1. Main System .....                                                            | 56 |
| B.1.1. Programming NV Register – Enabling 32-bit SPI Addressing .....             | 57 |
| B.1.2. Primary Main System.....                                                   | 58 |
| B.1.3. Golden Main System.....                                                    | 63 |
| B.1.4. Programming the MCS File .....                                             | 65 |

|                                                                                                  |     |
|--------------------------------------------------------------------------------------------------|-----|
| B.2. Node System .....                                                                           | 66  |
| Appendix C. Programming a Fresh Main System Board .....                                          | 73  |
| Appendix D. Checking Prints with MCS Manual and Automatic Booting .....                          | 78  |
| D.1. Checking the Primary Main System Standalone Project Prints .....                            | 78  |
| D.2. Checking the Golden Main System Standalone Project Prints .....                             | 80  |
| D.3. Checking the Main System Primary_Golden MCS with Manual Booting Prints .....                | 82  |
| D.4. Check the Main System Primary_Golden MCS with Automatic Booting Prints .....                | 84  |
| D.5. Checking the Main System Primary_Golden MCS with Automatic Booting Prints .....             | 86  |
| Appendix E. Ethernet Connection .....                                                            | 88  |
| E.1. Connection Between Main system and Laptop/PC .....                                          | 88  |
| E.2. Ethernet Configuration Setting .....                                                        | 88  |
| E.3. Check the Connection with a Ping .....                                                      | 91  |
| E.4. UDP Packet Transaction .....                                                                | 91  |
| E.5. Packet Sender Commands .....                                                                | 96  |
| E.5.1. Motor Config Commands .....                                                               | 96  |
| E.5.2. Recommend Command Sequences to Test Basic Functionality .....                             | 97  |
| Appendix F. Troubleshooting .....                                                                | 98  |
| F.1. Automate 3.1 User Interface Troubleshooting .....                                           | 98  |
| F.1.1. Motor Configuration Values are 0 .....                                                    | 98  |
| F.1.2. Motor Status Tab Failure (RPM Lock Status, Voltage Status and Drive Status are Red) ..... | 101 |
| F.1.3. One of the Selected Motor Running Warning .....                                           | 101 |
| F.1.4. Did not Receive Response from the Board Warning .....                                     | 102 |
| F.1.5. Allowing Permission to Publisher and Subscriber .....                                     | 104 |
| Annexure-A .....                                                                                 | 106 |
| References .....                                                                                 | 107 |
| Technical Support Assistance .....                                                               | 108 |
| Revision History .....                                                                           | 109 |

## Figures

|                                                                                                           |    |
|-----------------------------------------------------------------------------------------------------------|----|
| Figure 2.1. System Block Diagram.....                                                                     | 11 |
| Figure 3.1. OPCUA High-Level Block Diagram.....                                                           | 12 |
| Figure 3.2. Main and Node System Block Diagram.....                                                       | 12 |
| Figure 3.3. UDP IP Core Overview.....                                                                     | 13 |
| Figure 4.1. System Setup with Host PC (Example with One Node).....                                        | 15 |
| Figure 4.2. Main System Ready LEDs.....                                                                   | 16 |
| Figure 4.3. Node System Ready LEDs.....                                                                   | 16 |
| Figure 7.1. User Interface Application Login Screen.....                                                  | 19 |
| Figure 7.2. User Interface Application Dashboard Tab.....                                                 | 20 |
| Figure 7.3. User Interface Application System Configuration: IP Address.....                              | 20 |
| Figure 7.4. User Interface Application System Configuration: Updated Successfully Pop-up.....             | 21 |
| Figure 7.5. User Interface Application System Configuration: IP Address Configured Status.....            | 21 |
| Figure 7.6. User Interface Application Dashboard: List Status.....                                        | 22 |
| Figure 7.7. User Interface Application Dashboard: 2 Nodes Connected.....                                  | 22 |
| Figure 7.8. User Interface Application Dashboard: 1 Node Connected after Refresh.....                     | 23 |
| Figure 7.9. User Interface Application System Configuration: Motor Config File.....                       | 23 |
| Figure 7.10. User Interface Application System Configuration: Updated Successfully Pop-up.....            | 24 |
| Figure 7.11. User Interface Application Motor Configuration: Node Selection.....                          | 24 |
| Figure 7.12. User Interface Application Motor Configuration: Node Selected.....                           | 25 |
| Figure 7.13. User Interface Application Motor Configuration: Configuration Value Changes.....             | 26 |
| Figure 7.14. User Interface Application Motor Configuration: Warning Message.....                         | 26 |
| Figure 7.15. User Interface Application Motor Configuration: Authentication Pop-up.....                   | 26 |
| Figure 7.16. User Interface Application Motor Configuration: Update Configuration.....                    | 27 |
| Figure 7.17. Motor Config File Saved in Host PC.....                                                      | 27 |
| Figure 7.18. Motor Config.txt file in Host PC.....                                                        | 27 |
| Figure 7.19. User Interface Application Dashboard: Set Target RPM.....                                    | 28 |
| Figure 7.20. User Interface Application Dashboard: Start/Update.....                                      | 28 |
| Figure 7.21. User Interface Application Dashboard: RPM Lock Achieved Status.....                          | 29 |
| Figure 7.22. User Interface Application Motor Status: RPM Lock, Voltage, and Drive Status.....            | 29 |
| Figure 7.23. User Interface Application Dashboard: Stop and Power Off Buttons.....                        | 30 |
| Figure 7.24. User Interface Application Motor Status: Start/Update.....                                   | 31 |
| Figure 7.25. User Interface Application Motor Status: RPM Lock Status When Target RPM is Achieved.....    | 31 |
| Figure 7.26. User Interface Application Motor Status – Forward Rotation Status.....                       | 32 |
| Figure 7.27. User Interface Application Motor Status – Reverse Rotation Status.....                       | 33 |
| Figure 7.28. User Interface Application Motor Status – Motor Power Off.....                               | 33 |
| Figure 7.29. User Interface Application PDM Data: Path Name.....                                          | 34 |
| Figure 7.30. User Interface Application PDM Data: Updated Successfully Pop-up.....                        | 34 |
| Figure 7.31. User Interface Application PDM Data: Collect PDM Data.....                                   | 35 |
| Figure 7.32. User Interface Application PDM Data: Collecting PDM Data from Node.....                      | 35 |
| Figure 7.33. User Interface Application PDM Data: Analyzing PDM Data from Node.....                       | 36 |
| Figure 7.34. User Interface Application PDM Data: PDM Image.....                                          | 36 |
| Figure 7.35. User Interface Application PDM Data: Clear Status and Motor Status.....                      | 37 |
| Figure 7.36. User Interface Application PDM Data: Browse Button and Zoom Slider.....                      | 37 |
| Figure 7.37. User Interface Application PDM Batch Mode: Number of PDM files.....                          | 38 |
| Figure 7.38. User Interface Application PDM Batch Mode: Updated Successfully Pop-up.....                  | 38 |
| Figure 7.39. User Interface Application PDM Batch Mode: Start.....                                        | 38 |
| Figure 7.40. User Interface Application PDM Batch Mode: Batch Mode 100% Status.....                       | 39 |
| Figure 7.41. User Interface Application PDM Batch Mode: Collecting Multiple Images.....                   | 39 |
| Figure 7.42. User Interface Application PDM Data: Normal Mode.....                                        | 40 |
| Figure 7.43. User Interface Application PDM Data: Components Involved in PDM Data Collection Process..... | 40 |

|                                                                                                                                           |    |
|-------------------------------------------------------------------------------------------------------------------------------------------|----|
| Figure 7.44. User Interface Application PDM Data: Process Flow for PDM Data Collection .....                                              | 41 |
| Figure 7.45. Three Resistor Switches Tilted Towards the Resistors (Meaning All Three Resistors are Enabled and the Motor is "good") ..... | 42 |
| Figure 7.46. PDM Data collection: Example PDM Image of a Faulty Motor .....                                                               | 42 |
| Figure 7.47. Certus NX Board – I <sup>2</sup> C Connection .....                                                                          | 43 |
| Figure 7.48. Certus NX Board - SPI Connection.....                                                                                        | 43 |
| Figure 7.49. Total Phase - Adapter Setting (I <sup>2</sup> C).....                                                                        | 44 |
| Figure 7.50. Total Phase - I <sup>2</sup> C-SPI Selection .....                                                                           | 44 |
| Figure 7.51. Total Phase - I <sup>2</sup> C Control (I <sup>2</sup> C).....                                                               | 45 |
| Figure 7.52. Total Phase - SPI Control: SPI Enable .....                                                                                  | 45 |
| Figure 7.53. Total Phase - I2C and SPI Control Enabled .....                                                                              | 46 |
| Figure 7.54. Application Software - Node Peripherals: I <sup>2</sup> C-Write .....                                                        | 46 |
| Figure 7.55. Total Phase - Transaction Log-I <sup>2</sup> C.....                                                                          | 46 |
| Figure 7.56. Total Phase Aardvark I <sup>2</sup> C Control User Interface .....                                                           | 47 |
| Figure 7.57. Total Phase - Transaction Log - I <sup>2</sup> C.....                                                                        | 47 |
| Figure 7.58. Application Software – Node Peripherals: I <sup>2</sup> C-Read .....                                                         | 47 |
| Figure 7.59. Application Software - Node Peripherals: SPI-Write.....                                                                      | 48 |
| Figure 7.60. Total Phase - Adapter Setting: Transaction Log -SPI .....                                                                    | 48 |
| Figure 7.61. Total Phase - Adapter Setting: SPI Control.....                                                                              | 49 |
| Figure 7.62. Total Phase - Adapter Setting: Transaction Log-SPI .....                                                                     | 49 |
| Figure 7.63. Application Software - Node Peripherals: SPI-Read.....                                                                       | 49 |
| Figure 7.64. Application Software - Node Peripherals: Modbus-Write .....                                                                  | 50 |
| Figure 7.65. Docklight COM Selection .....                                                                                                | 50 |
| Figure 7.66. USB Serial Port Selection.....                                                                                               | 50 |
| Figure 7.67. Docklight - Project Settings.....                                                                                            | 51 |
| Figure 7.68. Docklight - Run.....                                                                                                         | 51 |
| Figure 7.69. Application Software- Node Peripheral: Modbus-Write.....                                                                     | 51 |
| Figure 7.70. Docklight Prints .....                                                                                                       | 51 |
| Figure A.1. Installer Directory .....                                                                                                     | 52 |
| Figure A.2. Automate 3.1 Initial Installation Setup .....                                                                                 | 52 |
| Figure A.3 Automate 3.1 Next Step .....                                                                                                   | 53 |
| Figure A.4. Automate 3.1 Next Step .....                                                                                                  | 53 |
| Figure A.5. Automate 3.1 Click Install .....                                                                                              | 54 |
| Figure A.6. Allow Permission Window .....                                                                                                 | 54 |
| Figure A.7. Automate 3.1 Installation in Progress .....                                                                                   | 55 |
| Figure A.8. Automate 3.1 Installation Finish.....                                                                                         | 55 |
| Figure B.1. Main System Jumper Connection .....                                                                                           | 56 |
| Figure B.2. Radiant Programmer – Configure NV Register 1 Setting .....                                                                    | 57 |
| Figure B.3. Radiant Programmer – Configure NV Register 1 Setting: Change Chip Value .....                                                 | 57 |
| Figure B.4. Radiant Programmer - Default Screen (Main System).....                                                                        | 58 |
| Figure B.5. Radiant Programmer - Initial Project Window (Main System).....                                                                | 58 |
| Figure B.6. Radiant Programmer - Device Selection (Main System) .....                                                                     | 59 |
| Figure B.7. Radiant Programmer - Device Operation (Main System) .....                                                                     | 59 |
| Figure B.8. Radiant Programmer - Erase All (Main System).....                                                                             | 60 |
| Figure B.9. Radiant Programmer - Bitstream Flashing Settings (Main System) .....                                                          | 61 |
| Figure B.10. Radiant Programmer - Binary Flashing Settings .....                                                                          | 62 |
| Figure B.11. Radiant Programmer - Binary Flashing Settings .....                                                                          | 63 |
| Figure B.12. Radiant Programmer - Bitstream Flashing Settings .....                                                                       | 64 |
| Figure B.13. Radiant Programmer - MCS Flashing Settings .....                                                                             | 65 |
| Figure B.14. Node System Jumper Connection.....                                                                                           | 66 |
| Figure B.15. Radiant Programmer - Default Screen (Node System) .....                                                                      | 67 |
| Figure B.16. Radiant Programmer - Initial Project Window (Node System) .....                                                              | 67 |

|                                                                                    |    |
|------------------------------------------------------------------------------------|----|
| Figure B.17. Radiant Programmer - Device Properties (Node System).....             | 68 |
| Figure B.18. Radiant Programmer - Device Operation (Node System) .....             | 68 |
| Figure B.19. Radiant Programmer - Erase All (Node System) .....                    | 69 |
| Figure B.20. Radiant Programmer - Bit Stream Flashing Settings (Node System) ..... | 70 |
| Figure B.21. Radiant Programmer - Binary Flashing Settings (Node System) .....     | 71 |
| Figure B.22. Reset Button SW3 of CertusPro NX Versa Board.....                     | 71 |
| Figure B.23. Button SW3 of Certus NX Versa Board .....                             | 72 |
| Figure C.1. Radiant Programmer - Default Screen .....                              | 73 |
| Figure C.2. Radiant Programmer - Initial Project Window.....                       | 73 |
| Figure C.3. Radiant Programmer - Device Selection .....                            | 74 |
| Figure C.4. Radiant Programmer - Device Operation .....                            | 74 |
| Figure C.5. Radiant Programmer - Quad Mode Programming.....                        | 75 |
| Figure C.6. Radiant Programmer - Device Properties .....                           | 76 |
| Figure C.7. Radiant Programmer - Erase All.....                                    | 77 |
| Figure D.1. Open Propel Terminal.....                                              | 78 |
| Figure D.2. Propel Terminal Selection Window .....                                 | 79 |
| Figure D.3. Propel Terminal - Com and Baud Rate Selection.....                     | 79 |
| Figure D.4. Primary Main System Propel Prints .....                                | 80 |
| Figure D.5. Packet Sender Application: Load file .....                             | 81 |
| Figure D.6. Packet Sender Application: Send UDP Rx Packet .....                    | 81 |
| Figure D.7. Golden Main System Propel Prints .....                                 | 82 |
| Figure D.8. Primary CRC Match Main System Propel Prints .....                      | 83 |
| Figure D.9. Golden CRC Match Main System Propel Prints .....                       | 84 |
| Figure D.10. Primary CRC Mismatch Main System Propel Prints.....                   | 85 |
| Figure D.11. Golden CRC Match Main System Propel Prints .....                      | 86 |
| Figure D.12. Primary CRC Match Main System Propel Prints .....                     | 87 |
| Figure D.13. Golden CRC Mismatch Main System Propel Prints.....                    | 87 |
| Figure E.1. Run the ncpa.cpl to Open the Network Connections Control Panel .....   | 88 |
| Figure E.2. Ethernet Settings .....                                                | 88 |
| Figure E.3. Ethernet Status – Properties Window .....                              | 89 |
| Figure E.4. Ethernet Properties – Internet Protocol Version Window.....            | 89 |
| Figure E.5. Configure the Settings.....                                            | 90 |
| Figure E.6. Disable the Setting .....                                              | 90 |
| Figure E.7. Enable the Setting .....                                               | 91 |
| Figure E.8. Ping on cmd Terminal .....                                             | 91 |
| Figure E.9. Wireshark Downloadable Link .....                                      | 92 |
| Figure E.10. Packet Sender Downloadable Link.....                                  | 92 |
| Figure E.11. Docklight - Com Selection .....                                       | 92 |
| Figure E.12. Docklight - Com and Baud Rate Selection .....                         | 93 |
| Figure E.13. Docklight - Run (Start Communication) .....                           | 93 |
| Figure E.14. Wireshark Tool - Ethernet Selection .....                             | 93 |
| Figure E.15. Packet Sender Tool - Send 64 Bytes of ASCII Characters .....          | 94 |
| Figure E.16. Packet Sender Tool - Send UDP Packet.....                             | 94 |
| Figure E.17. Packet Sender Tool - Transaction Log .....                            | 94 |
| Figure E.18. Docklight - Logs in ASCII .....                                       | 94 |
| Figure E.19. Wireshark Tool - Write udp.port == 1486 .....                         | 95 |
| Figure E.20. Source and Destination UDP Packet .....                               | 95 |
| Figure E.21. Wireshark Tool - First UDP Packet .....                               | 95 |
| Figure E.22. Wireshark Tool - Second UDP Packet.....                               | 95 |
| Figure F.1. Motor Configuration Values are All 0.....                              | 98 |
| Figure F.2. Motor Configuration: Node Selection.....                               | 99 |
| Figure F.3. Motor Configuration: All Nodes Selected .....                          | 99 |

Figure F.4. Motor Configuration Value Changes.....100

Figure F.5. Application Software - Motor Configuration: Warning Message.....100

Figure F.6. Application Software - Motor Configuration: Authentication Pop-up.....100

Figure F.7. Application Software - Motor Configuration: Update Configuration.....101

Figure F.8. Application Software- Motor Status Tab: Red Status.....101

Figure F.9. Motor Running Warning Message .....101

Figure F.10. Motor Connection Message.....102

Figure F.11. Motor Connection Message.....102

Figure F.12. Send/Receive on Comm. Channel .....102

Figure F.13. Project Settings .....103

Figure F.14. Run Button .....103

Figure F.15. ASCII Print Statements .....103

Figure F.16. Automate 3.1 User Interface.....104

Figure F.17. Allow Permission: Subscriber .....104

Figure F.18. Allow Permission: Publisher .....105

Tables

Table 6.1. Golden Project Files .....18

Table 6.2. Primary Project Files .....18



## Acronyms in This Document

A list of acronyms used in this document.

| Acronym | Definition                                       |
|---------|--------------------------------------------------|
| BLDC    | Brushless Direct Current                         |
| FPGA    | Field Programmable Gate Array                    |
| IIOT    | Industrial Internet of Things                    |
| IP      | Internet Protocol                                |
| OPCUA   | Open Platform Communications United Architecture |
| SPI     | Serial Peripheral Interface                      |
| UART    | Universal Asynchronous Receiver Transmitter      |
| UDP     | User Datagram Protocol                           |

# 1. Introduction

The Lattice Automate™ Stack showcases a variety of solutions for industrial automation. The Automate demo uses an end-to-end system for motor control and ML/AI powered predictive maintenance. However, the components of the Automate Stack are flexible enough to be applicable for a wide range of industrial automation use cases.

There are two FPGA systems in the Automate Stack: the Main System and the Node System.

The node system controls a motor and collects the data from the motor for the predictive maintenance neural network to use. The node system can connect to external sensors through three different protocols (SPI, UART/Modbus, and I<sup>2</sup>C), and has two-way communication with the main system through Etherconnect.

The main system has a RISC-V CPU running FreeRTOS, a real time operating system often used in embedded applications.

All modules in the main system and the node system FPGA designs are connected to each other using an AXI4 bus interface. This interface has high throughput and can run at a frequency of up to 100 MHz. It allows parallel data transfer, meaning a read and a write between two modules on the AXI bus can happen simultaneously.

The main system acts as a central hub which passes commands to up to eight different node systems. The main system also contains the AI/ML powered predictive maintenance system, which uses a neural network to analyze the collected data and predict failure ahead of time. In the Automate demo, this collected data is the current signature of the motor, but the PDM IP block can use any quantitative data for its input if the neural network is trained on the same type of data.

The Lattice Automate 3.1 solution stack uses the Golden System reference design (GSRD) developed on Lattice CertusPro™-NX FPGA as a base starting template. For Automate 3.1, the key IP blocks like UDP and EtherConnect are easily integrated into the GSRD template to build the entire Automate embedded system.

The Golden Software Reference Design (GSRD) is a comprehensive embedded system created by incorporating GHRD with the necessary device drivers. GSRD is a thoroughly tested known good design showcasing a system using FPGA-based RISC-V soft processor, intended to be used as a baseline project.

The GSRD comprises of the following components:

- GHRD (Hardware components designed by Lattice and can be easily build using the Lattice Propel™ builder environment).
- Reference RISC-V software components:
  - Bootloader
  - FreeRTOS device drivers for all IPs
  - FreeRTOS sample applications

**Note:** For more details on GHRD and GSRD, refer to the [GHRD/GSRD Reference Design](#) web page.

With the addition of these IP the total device usage is about 85% while still providing users with additional resource to implement minor design customization.

Moreover, Automate Stack 3.1 supports OPC-UA based packet exchange between the Main and Node system for various data transfers. OPC-UA, which stands for Open Platform Communications Unified Architecture, is a standardized communication framework designed for industrial automation and the Industrial Internet of Things (IIoT). This platform-independent and service-oriented architecture facilitates secure data exchange among diverse industrial systems. OPC-UA is known for its versatility, supporting various communication models and data types. With features such as platform independence, robust security mechanisms, and extensibility, OPC UA has become a widely embraced protocol in industrial communication. It plays a crucial role in enabling seamless connectivity and information exchange across different devices and systems in a standardized fashion.

**Note:** For more details on the OPC-UA, refer to [Automate Stack 3.1 Reference Design \(FPGA-RD-02284\)](#).

In the Automate system, you interact with the main system through the user application running on a PC. The user interface and main system are connected with an Ethernet cable and communicate with each other using OPC-UA, a machine-to-machine pub-sub communication protocol frequently used in the IIoT.

## 2. Demo System Setup

The Automate demo uses one main system (running on a CertusPro-NX Versa board) and at least one node system (running on a Certus™-NX Versa board). It can support up to 16 node systems. It is recommended only to run up to eight node systems for best performance. Each node system is connected to a motor driver board, which is connected to a brushless DC motor. The main system holds the predictive maintenance CNN co-processor.

The main system connects to the Host PC. The Host PC communicates through OPCUA with a PC running the user interface (Lattice Automate 3.1), through which you interact with the motors and receives PDM data.

### 2.1. System Level Block Diagram

Figure 2.1 shows the system-level block diagram. The Host PC running the Automate 3.1 user interface is connected to the main system over a standard 1G Ethernet cable. The main system running on CertusPro-NX is connected to the node system over EtherConnect.




Figure 2.1. System Block Diagram

### 3. Communication Protocols (OPCUA)

Automate 3.1 uses OPCUA as a data exchange standard for communication between the host PC and the main system FPGA board. This protocol is frequently used in IIOT settings.

#### 3.1. Main System to Host PC Communication - OPCUA

OPCUA is a cross-platform open-source data exchange standard developed by the OPC Foundation. It is frequently used in industrial applications for machine-to-machine communication. The OPCUA standard can be implemented on various platforms and is independent of the communication protocol. It was originally developed for data collection and control for industrial equipment, but it has now scaled to be appropriate for many more use cases, including building automation and cloud applications.

OPCUA has two variations, client/server and publish/subscribe. Automate 3.1 uses the publish/subscribe version of OPCUA.




Figure 3.1. OPCUA High-Level Block Diagram

#### 3.2. Main System to Node System Communication – OPCUA

The Main system and Node system communicate using the OPC UA protocol (client server mode). The Main system acts as the central hub for the system, receiving requests from the host PC and routing the relevant ones to the appropriate Node system based on their intended purpose. The Node system is responsible for performing operations based on the requests received from the Main system and sending the results back to the Main system for further processing.




Figure 3.2. Main and Node System Block Diagram

### 3.3. Node System to Node System Communication


Each node is connected in a chain of sequential nodes. It can communicate with the master using port 0 and can be connected to another Node module using port 1 for the first node. For subsequent nodes, node 0 is connected using port 0, and node 2 is connected using port 1, continuing in this sequential chain of nodes. Synchronization between different nodes is required to drive each node simultaneously.

### 3.4. UDP Communication

User Datagram Protocol (UDP/IP) is a communications protocol used for establishing connections between applications on the Internet. The UDP Protocol is a transport layer that operates atop the Internet Protocol (IP) Layer and is used for connections where high sustained throughput is a requirement and some data loss is anticipated, such as video and audio streaming. This UDP IP core for FPGAs offers minimal latency and bandwidth overhead since it transmits data packets without verifying reception and it can support up to 1 Gbps for any low-cost FPGA operating at 125 MHz.

A simple AXI streaming interface is all that is required to start sending and receiving UDP datagrams, and only the user data payload is exchanged between the application and the UDP core. The source UDP port, destination UDP port, destination IP address, and MAC address can be configured through the APB interface. These components can be easily enabled or disabled as needed by the user's application.

The core is delivered in a format that allows direct connection to the Lattice 1G TSE Ethernet MAC IP Core.



**Figure 3.3. UDP IP Core Overview**

## 4. Hardware

To demonstrate the Lattice Automate Solution stack, the below hardware is required. In the current demo a brushless DC (BLDC) motor is used from Anaheim Automation, but user can use any other BLDC motor which has a similar configuration. For the demo to run successfully, the users need to connect at least one node system to the main system.

### 4.1. Hardware Requirements

This demonstration requires the following hardware components:

- Main system:
  - Lattice CertusPro-NX Versa Evaluation Board
  - USB Type-A (UART) cable for programming the bitstream and binary files  
**Note:** One cable can be reused to program the main system and each node system, one at a time.
  - Electrical 1G SFP(s) Model FS SFP-GB-GE-T to make an Ethernet connection on the main system board (Insert at J15 ports of CertusPro-NX Versa Board).
  - Ethernet cable to connect the main system to the host PC
  - 12 V power adapter for board power
- Node system(s):  
**Note:** Demo supports up to 16 node systems. Requirements for 1 node system are listed:
  - Lattice Certus-NX Versa Evaluation Board(s)
  - 12 V power adapter(s) for board power
  - Ethernet cable(s) to connect the node system to the main system, and daisy chain node system boards.
  - Aardvark I2C/SPI Host Adapter to test Node peripheral interfaces (optional)
- Motor(s):
  - Anaheim Automation Brushless DC Motor(s) Model GB-42 BLS 24 V, 5000 RPM
  - Trenz TEP0002 motor control board(s)
  - 24 V-10 Amp DC Power Supply for motor(s)
- User interface (client system):
  - PC running Windows 10 Operating System of 1920 x 1080 resolution, 100% dpi

### 4.2. Hardware Setup

The details of the hardware connections are illustrated in [Figure 4.1](#).




Figure 4.1. System Setup with Host PC (Example with One Node)

## 4.3. Hardware System Readiness

### 4.3.1. FPGA Board Programming

To program the FPGA board:

1. Hardware should be connected properly as shown in [Figure 4.1](#).
2. All boards should be programmed with .bit and .bin files.
  - a. If the user is using a brand new CertusPro-NX Versa board, refer to the [Appendix C. Programming a Fresh Main System Board](#) section for programming.
  - b. Otherwise, for main and node systems, refer to the [Appendix A. User Interface Application Installation \(PC\)](#) section for board programming.
3. Power cycle every board after programming.
4. After the power cycle, reset the main system (press the SW3 button on the main system).

### 4.3.2. Power-up Sequence

To start power-up sequence:

1. Power on the Host PC.
2. Power on the node system, motor driver, and motors.
3. Power on the main system.

### 4.3.3. Status LEDs on Boards

1. Check the main and node system ready LEDs to check connections:
  - a. Main System:
    - D67: Main System Power On
    - D64: Main System Ready
    - D63: Ethernet Connection Established
  - b. Node System:
    - D32 and D34: Link up LEDs



- D30: Illuminates if the next node in the chain is connected. (Not needed for the last node in the chain.)
- D18 - D25: Node system ready
- 7-segment LED: Node system ready

**Note:** Wait 60 seconds after power on for these LEDs to illuminate. If the above LEDs are not all illuminated, power cycle all boards and/or refer to the [Appendix F. Troubleshooting](#) section.




Figure 4.2. Main System Ready LEDs




Figure 4.3. Node System Ready LEDs



## 5. Software Requirements

- Lattice Radiant 2022.1 or later  
Lattice Radiant Programmer 2022.1 or later (part of Radiant install). The following required software programs are available here: [www.latticesemi.com/en/Products/DesignSoftwareAndIP](http://www.latticesemi.com/en/Products/DesignSoftwareAndIP).
- Lattice Automate demo bitstreams and binaries are available here under the Design File section:  
<https://www.latticesemi.com/en/Solutions/Solutions/SolutionsDetails02/Automate>
- Lattice Automate 3.1 Test Application Software  
**Note:** Lattice Automate 3.1 is available in OPCUA to publish/subscribe version.  
The software programs are available for download only if the user log in at [www.latticesemi.com](http://www.latticesemi.com).

### 5.1. Optional Software

- Total Phase Control Center 4.1 or later for testing node peripherals (purchase may be needed)
- Wireshark 4.2.0 or later (open source)
- Packet Sender 8.5.2 or later (open source)
- Docklight v2.4 or later (open source)

### 5.2. Software System Readiness

To check the software system readiness:

1. Establish the Ethernet connection before connecting to the user interface.
  - a. Follow steps A through C in the [Ethernet Connection](#) section to establish the Ethernet connection.
2. User interface installation and running:
  - a. Refer to [User Interface Application Installation \(PC\)](#) section to install the user interface application on the PC (one time).
  - b. Refer to the [Running the Motor through Automate User Interface Application \(PC\)](#) section to run the user interface application on the PC (every time the user run the demo).

## 6. Automate Stack File Directory Structure

All files can be downloaded from [www.latticesemi.com/Solutions/Solutions/SolutionsDetails02/Automate](http://www.latticesemi.com/Solutions/Solutions/SolutionsDetails02/Automate).

### 6.1. Executables

These files are programmed onto the main and node FPGA boards.

#### 6.1.1. Main System

The Main System has the following folders.

##### 6.1.1.1. Golden Folder

**Table 6.1. Golden Project Files**

| File Description            | File Name                  | Starting Address in Flash |
|-----------------------------|----------------------------|---------------------------|
| Golden FW Image without CRC | Golden_App.bin             | 0x02_000_000              |
| Golden FW Image             | Golden_AppCrc.bin          | 0x02_000_000              |
| Golden FPGA Image           | soc_main_system_impl_1.bit | 0x00_000_000              |

##### 6.1.1.2. MCS Folder

The MCS file has both the main system and the golden project files combined into one single file.

- soc\_main\_system\_3\_1\_impl\_1.mcs

##### 6.1.1.3. Primary Folder

**Table 6.2. Primary Project Files**

| File Description             | File Name                      | Starting Address in Flash |
|------------------------------|--------------------------------|---------------------------|
| Primary FW Image without CRC | c_main_system_3_1_cnn.bin      | 0x02_0A0_000              |
| Primary FW Image             | c_main_system_3_1_cnnCRC.bin   | 0x02_0A0_000              |
| Primary FPGA Image           | soc_main_system_3_1_impl_1.bit | 0x00_000_000              |

#### 6.1.2. Node System

- c\_node\_system\_3\_1.bin
- soc\_node\_impl1.bit

### 6.2. User Interface

Install the *Automate3p1GUI.exe\_user* interface to the Host PC.

## 7. Running the Motor through Automate User Interface Application (PC)

The Lattice Automate 3.1 user interface is developed for users to easily control the motor behavior from the host PC. This user interface allows you to update motor parameters and control the speed and directions of all the motors. The motor running procedure is defined in this section through a Graphical User Interface/Test Application.

**Note:** For Lattice Automate Stack 3.1 Application Installation on the PC, refer to [Appendix A. User Interface Application Installation \(PC\)](#) section. For programming the main system and node system boards, refer to [Appendix B. Programming the Automate Stack on Respective Flash](#) section.

### 7.1. Starting the Application on Host PC

To start the application on host PC:

1. Open the Lattice Automate application.




Figure 7.1. User Interface Application Login Screen

2. Enter the credentials and click **Login**:
  - **Username:** lattice
  - **Password:** lattice

After successful login, the **Dashboard** tab opens.




Figure 7.2. User Interface Application Dashboard Tab

## 7.2. Connect to the Main System

To connect to the main system:

1. Click on the **System Configuration** tab.






Figure 7.3. User Interface Application System Configuration: IP Address

2. Type the IP Address in the **IP Address** field.  
**Note:** Do not type leading zeros in the IP address, as shown in [Figure 7.3](#).
3. Click **Apply**. The **Updated Successfully** pop-up displays. The updated IP address is visible on top of the IP Address bar.



**Figure 7.4. User Interface Application System Configuration: Updated Successfully Pop-up**

4. Click **Connect**.
5. Once the IP Address is configured, the connection status is green and the IP Address bar disabled.



**Figure 7.5. User Interface Application System Configuration: IP Address Configured Status**

## 7.3. Dashboard Tab

Click the **Dashboard** tab as shown in [Figure 7.6](#). This displays the following details:

- Chain 1 Linkup status
- Active link status
- Check the Chain1 – nodes synchronization delay




Figure 7.6. User Interface Application Dashboard: List Status

## 7.4. Refresh Button

[Figure 7.7](#) shows the connected nodes. The Refresh button can be used to update nodes, if you are already connected and need to add or remove a node. To test and demonstrate its functionality, follow the steps below.




Figure 7.7. User Interface Application Dashboard: 2 Nodes Connected

To use the refresh button:

1. Disconnect the last node of the chain.
2. Wait for 10 seconds, then click **Refresh** button.
3. After Refresh completes, the dashboard reflects the actual connected node(s).



Figure 7.8. User Interface Application Dashboard: 1 Node Connected after Refresh

## 7.5. Motor Configurations

To configure the motor:

1. Click the **System Configuration** tab.
2. Click on the folder ( ) icon and select or create a location to save the motor config file. Save location can be anywhere in the system except C: drive.





Figure 7.9. User Interface Application System Configuration: Motor Config File




3. Click **Apply**.
4. Click **OK** on the **Updated Successfully** pop-up.




**Figure 7.10. User Interface Application System Configuration: Updated Successfully Pop-up**

5. Click on the **Motor Configuration** tab.
6. Select the number of nodes.



**Figure 7.11. User Interface Application Motor Configuration: Node Selection**

7. Either **Select All** to configure all the nodes at once or select one node at a time to configure it individually.



**Figure 7.12. User Interface Application Motor Configuration: Node Selected**

8. Change the Motor Configuration to the following values:

- RPI PI Control Prop. Gain(kP): **90**
- RPI PI Int. Gain(kI): **10**
- RPI PI Control delay: **200**
- Minimum Power: **190 - 200**
- Power gain: **22 – 24**
- Breaker Amps: **1.8 - 2.0**

**Note:** These configuration values are for the GB-42 BLS 24 V, 5000 RPM Motors only. Modify them as needed for a different motor.




Figure 7.13. User Interface Application Motor Configuration: Configuration Value Changes

9. Click **Save**.
10. Click **Default**.
11. Click **Update**. A pop message appears.
12. Confirm the update action by clicking **Yes**. This displays a Authentication pop-up.





Figure 7.14. User Interface Application Motor Configuration: Warning Message

13. Enter the following credentials and click **Login**:
  - **Username:** lattice
  - **Password:** lattice



Figure 7.15. User Interface Application Motor Configuration: Authentication Pop-up

14. Click **OK** in the **Successfully updated the configuration of the selected node** pop-up.




**Figure 7.16. User Interface Application Motor Configuration: Update Configuration**

15. Locate the `motor_config.txt` file. It is saved in the location that user selected in step 2.

| Name                                                                                                        | Date modified       | Type          | Size |
|-------------------------------------------------------------------------------------------------------------|---------------------|---------------|------|
|  <code>motor_config</code> | 27-12-2023 11:39 PM | Text Document | 1 KB |

**Figure 7.17. Motor Config File Saved in Host PC**

16. Open the `motor_config.txt` file and verify that the saved motor configurations match the values that user entered in step 7.



**Figure 7.18. Motor Config.txt file in Host PC**

## 7.6. Target RPM, Voltage, and Drive Status Using the Dashboard Tab

To target RPM, voltage, and drive status:

1. Click the **Dashboard** tab.
2. Enter the **Target RPM** Value as **120**.

**Note:** You can gradually increase the RPM up to 2000 RPM.

The following RPM increments are recommended: 120, 400, 800, 1400, 1600, 1800, and 2000.

**Note:** The target RPM value should not exceed the Maximum RPM value entered in the **Motor Configuration** tab.




Figure 7.19. User Interface Application Dashboard: Set Target RPM

3. Click **Start/Update**.




Figure 7.20. User Interface Application Dashboard: Start/Update

4. After the RPM Lock is achieved, the Node LED is green.




Figure 7.21. User Interface Application Dashboard: RPM Lock Achieved Status

5. Click the **Motor Status** tab to check the RPM, Voltage, and Current values.
6. Select the node that you want to check.





Figure 7.22. User Interface Application Motor Status: RPM Lock, Voltage, and Drive Status

7. To stop the motor, click **Stop** on either the **Motor Status** tab or the **Dashboard** tab.
8. Click **Power Off**.



**Figure 7.23. User Interface Application Dashboard: Stop and Power Off Buttons**

**Note:** The **Power Off** button disengages the motor power supply completely. This helps to prevent the motor from continuously drawing current from the power supply.

## 7.7. Motor Status Test

To check the motor status:

1. Click the **Motor Status** tab.
2. Set the Target RPM to **120**.

**Notes:**

- You can gradually increase the RPM up to 2000 RPM.
- The following RPM increments are recommended: 120, 400, 800, 1400, 1600, 1800, and 2000.
- Target RPM should not exceed the Maximum RPM value entered in the Motor Configuration tab.

3. Click **Start/Update**.




Figure 7.24. User Interface Application Motor Status: Start/Update

4. Once the actual RPM reaches the target RPM, the meter gauge displays 120 and the RPM Lock button becomes green.
5. To update the RPM speed, set the **Target RPM** to 500 RPM.
6. Once the actual RPM reaches the target RPM, the meter gauge displays 500 and the RPM Lock button becomes green.



Figure 7.25. User Interface Application Motor Status: RPM Lock Status When Target RPM is Achieved

7. To stop the motor, click **Stop**.
8. Click **Power Off** to stop the current withdraw.



## 7.8. Forward/Reverse Rotation Test

To test the forward/reverse rotation:

1. Click the **Motor Status** tab.
2. Select the **Forward** option for the rotation.
3. Enter the **Target RPM** anywhere between 120 RPM to 2000 RPM.
4. Click **Start/Update**. The Motor starts rotating in a clockwise direction.






Figure 7.26. User Interface Application Motor Status – Forward Rotation Status

5. Wait until the RPM Lock status becomes green.
6. Select the **Reverse** option to rotate the motor in the opposite direction.



**Figure 7.27. User Interface Application Motor Status – Reverse Rotation Status**

7. Click **Start/Update**. The Motor changes the direction to rotate in a counterclockwise direction.
8. Wait until the RPM Lock status becomes green.
9. To stop the motor, click **Stop**, and then **Power Off**.



**Figure 7.28. User Interface Application Motor Status – Motor Power Off**

## 7.9. PDM Data Collection

### 7.9.1. Collect PDM Data

To collect PDM data:

1. Click the **System Configuration** tab.
2. Click on the folder (  ) icon and select or create a location to save the PDM images. Save location can be anywhere in the system except C: drive.




Figure 7.29. User Interface Application PDM Data: Path Name

3. Click **Apply**. Click **OK** on the **Updated Successfully** pop-up.




Figure 7.30. User Interface Application PDM Data: Updated Successfully Pop-up

4. Click the **Motor Status** tab.
5. Set the **Target RPM** initially to 120, then gradually increase the RPM as described in [Motor Status Test](#) section.
6. Click **Start/Update**. Wait for the RPM lock.
7. Click **Collect PDM Data**. Wait for the PDM data process to complete. It may take a few minutes.




Figure 7.31. User Interface Application PDM Data: Collect PDM Data

8. Choose Normal or Extended for the Packet type. Both Normal mode and Extended mode appear the same from a user's perspective, but Extended mode is more efficient if there are many nodes in the chain.

**Note:** See [Details about PDM Data Collection Process](#) section for a description of Normal mode and Extended mode.

9. **Collecting PDM Data from Node** and **Analyzing PDM Data from Node** messages are displayed while the image is captured.






Figure 7.32. User Interface Application PDM Data: Collecting PDM Data from Node



**Figure 7.33. User Interface Application PDM Data: Analyzing PDM Data from Node**

10. Once the Collect PDM Data process is complete, the PDM image appears on the screen.



**Figure 7.34. User Interface Application PDM Data: PDM Image**

11. To remove the image and clear motor status, click **Clear Status**. Motor Status becomes yellow.




Figure 7.35. User Interface Application PDM Data: Clear Status and Motor Status

12. To fetch the previous images, click **Browse**.
13. To zoom in or zoom out the PDM image, move the cursor up or down on the zoom slider.





Figure 7.36. User Interface Application PDM Data: Browse Button and Zoom Slider

## 7.9.2. Batch Mode


Batch mode allows you to collect multiple PDM images, one after another. First, you must choose how many PDM files you want to collect. After that, the steps are like the standard Collect PDM Data process.

1. Click the **System Configuration** tab and enter the number of PDM files that you want to collect. The system supports a range of 1-20 PDM files.
2. If you have not yet selected a location to save the images, click the folder image next to Path Name and browse for a location, as described in the [Collect PDM Data](#) section, Step 2.




**Figure 7.37. User Interface Application PDM Batch Mode: Number of PDM files**

3. Click **Apply**.
4. Click **OK** on the **Updated Successfully** pop-up.



**Figure 7.38. User Interface Application PDM Batch Mode: Updated Successfully Pop-up**

5. Click the **Motor Status** tab.
6. Click on the **Start** button under the words Batch Mode.



**Figure 7.39. User Interface Application PDM Batch Mode: Start**

7. Wait for some time to collect multiple images until the status bar reaches 100%. This takes a few minutes. The more images that you are collecting, the longer it takes.




Figure 7.40. User Interface Application PDM Batch Mode: Batch Mode 100% Status

8. If you do not want to capture all the images, click **Stop** to stop the image collecting.




Figure 7.41. User Interface Application PDM Batch Mode: Collecting Multiple Images

9. Click **Stop** to stop the motor.
10. Click **Power Off**.



### 7.9.3. Details about PDM Data Collection Process

When you do a PDM data request in the user interface, the request is sent over OPCUA and a PDM Data command is sent through Etherconnect to the main system's RISC-V CPU. The main system first confirms that the motor is running, RPM is locked, and calibration is done.

The main system creates a frame and sends a packet through the control/PHY to the node system.

When the node system receives the frame, the node system's RISC-V CPU uses the PDM Data Collector to fill the FIFO DMA with data collected from the motor. When the FIFO DMA is full, an Ethercontrol packet is returned to the main system, using an interrupt to alert the main system that data is ready.

The ethernet packet continues making round trips. If the packet ID matches the request ID, then it contains valid data and is processed. Otherwise, the packet is discarded.

In both normal and extended mode, PDM data is collected for one node at a time. The node to collect data on must be selected in the user interface. In Extended mode, the number of transactions depends on the active nodes connected in the chain. As the number of active nodes increases, the number of transactions decreases, hence the time to collect PDM data also decreases.




Figure 7.42. User Interface Application PDM Data: Normal Mode





Figure 7.43. User Interface Application PDM Data: Components Involved in PDM Data Collection Process



**Figure 7.44. User Interface Application PDM Data: Process Flow for PDM Data Collection**

## 7.9.4. Collecting PDM Data from a Simulated Faulty Motor Using the Switches


### 7.9.4.1. Introduction and Purpose of the Switches

Normally, all the motors in the Automate demo should be working well and not failing. To show the benefits of the PDM data collection, the Automate demo setup includes three switches that control the power resistors connected to the motor. By toggling these switches, the user can disable the resistors and simulate what the motor would look like if it were failing or faulty.

Each switch is for one phase of the motor. When the switches are tilted towards the power resistors of the motor, this means the power resistors are included in the circuit and the motor should behave normally. If any single switch is tilted away from the power resistors of the motor, the resistor is disconnected, and the motor exhibits faulty behavior. This faulty behavior may not be observable to a human, which is where the power of PDM data collection comes in.

PDM data collection collects the current signature of the motor. Inside the PDM module, there is a convolutional neural network that has been trained on the current signatures of good and faulty motors. This setup can be extended to collect data at regular intervals and send an alert if one of the motors starts to show signs of failing. It is easy to see how early detection of a problem can save time and expense in an industrial automation scenario.

**Safety Note:** Only one resistor should be disabled at a time. In other words, only tilt one switch away from the motor at a time. If two or three switches are tilted away at the same time, the motor does not rotate, and the motor can be damaged.




**Figure 7.45. Three Resistor Switches Tilted Towards the Resistors (Meaning All Three Resistors are Enabled and the Motor is “good”)**

#### 7.9.4.2. Example Workflow to Collect Faulty PDM Data with the Switches

To collect faulty PDM data with switches:

1. Set the target initially to 120 RPM and start the motor.
2. Gradually increase the RPM as described in [Motor Status Test](#) section.
3. Continue increasing the RPM up to 1500.
4. Disable any one switch by tilting it away from the power resistors of the motor.
5. Follow the instructions in the [Collect PDM Data](#) section to collect PDM data in either Normal or Extended mode.
6. When the PDM image appears, the lines in the image should look different than the image collected when all the power resistors are enabled and the Motor Status icon should be red.



**Figure 7.46. PDM Data collection: Example PDM Image of a Faulty Motor**

7. Stop the motor and power it off.
8. Tilt the switch back towards the motor to re-enable the power resistor.

## 7.10. Testing Node Peripherals

To test the node peripherals:

1. Connect the I<sup>2</sup>C/SPI Host Adapter between the Lattice Certus NX board and Host PC-1.
2. For I<sup>2</sup>C connection, connect the SDA to pin 1 of JP3 and SCK pin to pin 2 of JP2 on the Lattice Certus NX board.
  - a. The arrow printed on the board indicates pin 1, so the other pin in the jumper pair is pin 2.




Figure 7.47. Certus NX Board – I<sup>2</sup>C Connection

3. For SPI Connection, connect the MISO, MOSI, SCK, and CS into J8 PMOD2 pins in the upper slot of the Certus NX board. Starts from the arrow:
  - a. Pin 1. MISO (PMOD 1)
  - b. Pin 2. MOSI (PMOD2)
  - c. Pin 3. SCLK (PMOD 3)
  - d. Pin 4. CS/SS (PMOD 4)
  - e. Connect the GND pin to the GND port of the Certus NX Board as shown in [Figure 7.48](#).




Figure 7.48. Certus NX Board - SPI Connection

### 7.10.1. Making the Connection in Total Phase Control Center

To make the connection in total phase control center:

1. Open **Total Phase Control Center**.
2. Click on the **Adapter** tab, and then Click **Connect**.




Figure 7.49. Total Phase - Adapter Setting (I<sup>2</sup>C)

3. Configure the adapter page opens. Select a Mode: I<sup>2</sup>C-SPI.
4. Click **OK**.




Figure 7.50. Total Phase - I<sup>2</sup>C-SPI Selection

5. Select the **Slave** tab on the I<sup>2</sup>C Control page.
6. Click **Enable**.

**Note:** Make sure that the physical connection between the Aardvark and PMOD of the node board is correct.




Figure 7.51. Total Phase - I<sup>2</sup>C Control (I<sup>2</sup>C)

7. Select the **Slave** tab on **SPI Control** page.
8. Click **Enable**.




Figure 7.52. Total Phase - SPI Control: SPI Enable

9. Once Enabled both I<sup>2</sup>C and SPI control, the display looks like [Figure 7.53](#) and the connection status shows in the transaction log.




Figure 7.53. Total Phase - I2C and SPI Control Enabled

### 7.10.2. I<sup>2</sup>C

For write operation:

1. In the Automate 3.1 user interface, click the **Node Peripherals** tab.
2. Select the **Node** which is connected to the Aardvark I<sup>2</sup>C/SPI Host Adapter.
3. Select the protocol: **I<sup>2</sup>C**
4. Select the operation: **Write**
5. Enter the Slave Address 2 bit: **5A**
6. Enter the Data 2 bit: 25 (User can write any data from 0x00 to 0xFF.)
7. Click **Write**.




Figure 7.54. Application Software - Node Peripherals: I<sup>2</sup>C-Write

8. In the Total Phase tool, check the transaction log.




Figure 7.55. Total Phase - Transaction Log-I<sup>2</sup>C

For read operation:

1. Using the Aardvark user interface, write the value 12 in the message box and click **Set Resp.**




Figure 7.56. Total Phase Aardvark I<sup>2</sup>C Control User Interface

2. Check the transaction log.

| Transaction Log         |      |     |     |       |      |       |        |      |  |
|-------------------------|------|-----|-----|-------|------|-------|--------|------|--|
| Time                    | Mod. | R/W | M/S | Feat. | B.R. | Addr. | Length | Data |  |
| 2022-12-01 12:08:51.848 | I2C  | S   | S   | ---   |      | 0X5A  | 1      | 12   |  |

Figure 7.57. Total Phase - Transaction Log - I<sup>2</sup>C

3. In the Node Peripherals tab of the Automate 3.1 user interface, select the Operation: **Read**.
4. Click **Read**. The data value read should be 12.





Figure 7.58. Application Software – Node Peripherals: I<sup>2</sup>C-Read



### 7.10.3. SPI

For the SPI write and read operation:

1. In the Automate 3.1 user interface, click the **Node Peripherals** tab.
2. Select the **Node** which is connected to the Aardvark I<sup>2</sup>C/SPI Host Adapter
3. Select the protocol: **SPI**
4. Select the operation: **Write**
5. Slave Address 2 bit: **Disabled**
6. Enter the Data 2 bit: 25 (you can write any data from 0x00 to 0xFF.)
7. Click **Write**.



**Figure 7.59. Application Software - Node Peripherals: SPI-Write**

8. In the Total Phase tool, check the transaction log.

**Note:** Make sure that the physical connection between the Aardvark and PMOD of the node board is correct.

| Transaction Log         |      |     |     |       |      |       |        |      |
|-------------------------|------|-----|-----|-------|------|-------|--------|------|
| Time                    | Mod. | R/W | M/S | Feat. | B.R. | Addr. | Length | Data |
| 2022-09-16 14:49:22.368 | SPI  | R   | S   | RSML  |      |       | 1      | 14   |
| 2022-09-16 14:49:22.368 | SPI  | W   | S   | RSML  |      |       | 1      | 00   |

**Figure 7.60. Total Phase - Adapter Setting: Transaction Log -SPI**

9. Write the value 22 in the MISO message box and click **Set MISO**.




Figure 7.61. Total Phase - Adapter Setting: SPI Control

10. Check the transaction log.

| Transaction Log         |      |     |     |       |      |       |        |      |
|-------------------------|------|-----|-----|-------|------|-------|--------|------|
| Time                    | Mod. | R/W | M/S | Feat. | B.R. | Addr. | Length | Data |
| 2022-12-01 12:23:36.232 | SPI  | S   | S   |       |      |       | 1      | 22   |

Figure 7.62. Total Phase - Adapter Setting: Transaction Log-SPI

11. In the **Node Peripherals** tab of the Automate 3.1 user interface, select the Operation: **Read**,
12. Click **Read**. The value in the field Data should match the value that was entered in step 9.




Figure 7.63. Application Software - Node Peripherals: SPI-Read

#### 7.10.4. Modbus


**Note:** Connect the UART cable from the UART port of the Node system to the PC/Laptop.

**Note:** Required tool: Docklight v2.4 or later.

For the Modbus write operation:


1. In the Automate 3.1 user interface, click the **Node Peripherals** tab.
2. Enter the Slave Address: 06 (you can enter 1-10).

3. Enter the Register Number: 07 (you can enter 0-9).
4. Enter the Data: 1285 (you can enter 0-FFFF).




**Figure 7.64. Application Software - Node Peripherals: Modbus-Write**

5. Open Docklight.
6. Double-click **COM**.



**Figure 7.65. Docklight COM Selection**

7. Select the last USB serial port in the list, as shown in Figure 7.66.



**Figure 7.66. USB Serial Port Selection**

8. Select the Baud Rate: **9600**.




Figure 7.67. Docklight - Project Settings

9. Click **Run**.




Figure 7.68. Docklight - Run

10. In the Automate 3.1 user interface, click **Write**.




Figure 7.69. Application Software- Node Peripheral: Modbus-Write

11. In Docklight, click the **HEX** tab. You can see the transmitted message printed in red.




Figure 7.70. Docklight Prints

## Appendix A. User Interface Application Installation (PC)

**Note:** This installation process is done on the PC to run the user application, such as a laptop or desktop PC.


To install the user interface application on a PC:

1. Download or locate the Lattice Automate 3.1 Installer.
2. Double-click on the installer to install the application.

| Name  | Date modified       | Type        | Size      |
|-------|---------------------|-------------|-----------|
| .svn  | 12-12-2023 05:34 PM | File folder |           |
| setup | 12-12-2023 05:34 PM | Application | 72,053 KB |

**Figure A.1. Installer Directory**

3. Wait for the installation to complete.



**Figure A.2. Automate 3.1 Initial Installation Setup**

4. Click **Next**.




Figure A.3 Automate 3.1 Next Step

5. Click **Next**.




Figure A.4. Automate 3.1 Next Step

6. Click **Install**.




Figure A.5. Automate 3.1 Click Install

7. Wait for the installation to complete. Click **Yes** to allow permission.




Figure A.6. Allow Permission Window




Figure A.7. Automate 3.1 Installation in Progress

8. Click **Finish**.




Figure A.8. Automate 3.1 Installation Finish



## Appendix B. Programming the Automate Stack on Respective Flash

### B.1. Main System

This section provides the procedure for programming the SPI Flash on the CertusPro-NX Versa board for the main system. Two different files should be programmed into the SPI Flash. These files are programmed to the same SPI Flash, but at different addresses:

- Bitstream (FPGA SoC Design)
- Binary (RISC-V Firmware)

#### Board Jumper Connections

The following jumpers must be connected on the board:

- Pin 1 and 2 of J32 and J33 must be shorted to select UART.
- Pin 1 and 2 of J58 should be shorted to select the 3.3 V as Flash I/O.




Figure B.1. Main System Jumper Connection

If the user programming the main system board for the first time, refer to the [Appendix C. Programming a Fresh Main System Board](#) section for more details. Once done, go back to this section to follow further steps.

B.1.1. Programming NV Register – Enabling 32-bit SPI Addressing

To program the NV register:

- 1. Apply the settings as shown in Figure B.2. This is a one-time step required to configure the NV Register 1 to enable 32-bit SPI addressing. Click **OK**.




Figure B.2. Radiant Programmer – Configure NV Register 1 Setting

- 2. Click the **Program Device** icon  or go to **Run > Program Device**.
- 3. Change the bit 0 to 1 as shown in Figure B.3.




Figure B.3. Radiant Programmer – Configure NV Register 1 Setting: Change Chip Value

- 4. After changing the bit, click **Program**.
- 5. Power cycle the CertusPro NX versa board.

## B.1.2. Primary Main System

### B.1.2.1. Programming the FPGA Bitstream

To program the FPGA bitstream in external SPI Flash using Radiant Programmer:

1. Connect the CertusPro-NX Versa board to the PC using a USB cable.
2. Start Radiant Programmer. In the Getting Started dialog box, select **Create a new blank project**.




Figure B.4. Radiant Programmer - Default Screen (Main System)

3. Click **OK**.




Figure B.5. Radiant Programmer - Initial Project Window (Main System)

4. In the Radiant Programmer main interface, select **LFCPNX** for **Device Family** and **LFCPNX-100** for **Device** or detect automatically as shown in Figure B.6.




Figure B.6. Radiant Programmer - Device Selection (Main System)

5. Right-click and select **Device Properties**.





Figure B.7. Radiant Programmer - Device Operation (Main System)


6. Before programming, apply the settings below to erase the flash memory:
  - a. Under Device Operation, select the options below:
    - Target Memory – **External SPI Flash Memory (SPI FLASH)**
    - Port Interface – **JTAG2SPI**
    - Access Mode – **Direct Programming**
    - Operation – **Erase all**
  - b. Under SPI Flash Options, select the options below:
    - Family – **SPI Serial Flash**
    - Vendor – **Macronix**
    - Device – **MX25L51245G**
    - Package – **8-land WSON**



**Figure B.8. Radiant Programmer - Erase All (Main System)**

7. Click **OK** and then click the Program Device icon  or go to **Run > Program Device**. This erases the flash memory if any other data is already present in it.
8. After erasing the flash, power cycle the board and apply the settings below:
  - a. Under Device Operation, select the options below:
    - Target Memory – **External SPI Flash Memory (SPI FLASH)**
    - Port Interface – **JTAG2SPI**
    - Access Mode – **Direct Programming**
    - Operation – **Erase, Program, Verify**
  - b. Under SPI Flash Options, select the options below:
    - Family – **SPI Serial Flash**
    - Vendor – **Macronix**
    - Device – **MX25L51245G**
    - Package – **8-land WSON**

9. To program the **bitstream file**, select the options as shown in [Figure B.9](#).




**Figure B.9. Radiant Programmer - Bitstream Flashing Settings (Main System)**

- a. Under **Programming Options**, select the **soc\_main\_system\_impl\_1.bit** bitstream file in the Programming file.
  - b. Click **Load from File** to update the Data file size (Bytes) value.
  - c. Make sure that the following addresses are correct:
    - Start Address (Hex) – **0x00000000**
    - End Address (Hex) – **0x00280000**
10. Click the Program Device icon  or go to **Run > Program Device**.

### B.1.2.2. Primary Main System Firmware

To program the firmware, perform the following steps:

1. Select the options as shown in [Figure B.10](#).
  - a. Under Programming Options, select the **c\_main\_system\_3\_1\_cnnCrc.bin** binary file.
  - b. Make sure that the following addresses are correct:
    - **Start Address (Hex) – 0x020A0000**
    - **End Address (Hex) – 0x020D0000**




**Figure B.10. Radiant Programmer - Binary Flashing Settings**

2. Click the Program Device icon  or go to **Run > Program Device**.
3. Power cycle the CertusPro NX versa board.

### B.1.3. Golden Main System

To program the firmware in the SPI Flash in Radiant Programmer:

1. Select the options as shown in [Figure B.11](#).
  - a. Under Programming Options, select the **Golden\_AppCrc.bin** binary file.
  - b. Make sure that the following addresses are correct:
    - **Start Address (Hex) – 0x02000000**
    - **End Address (Hex) – 0x02030000**



**Figure B.11. Radiant Programmer - Binary Flashing Settings**

2. Click the Program Device icon  or go to **Run > Program Device**




### B.1.3.1. Golden Main System Bitstream

**Note:** The bitstream steps below are only valid for standalone projects. No need to program the bitstream while programming the MCS file.

After erasing the flash, perform the steps below:

1. Power cycle the board and apply the settings below:
  - a. Under Programming Options, select the **soc\_main\_system\_impl\_1.bit** bitsream file.
  - b. Click **Load** from File to update the Data file size (Bytes) value.
  - c. Make sure that the following addresses are correct:
    - **Start Address (Hex) – 0x00000000**
    - **End Address (Hex) – 0x00240000**
  - d. To program the bitstream, select the options as shown in Figure B.12




**Figure B.12. Radiant Programmer - Bitstream Flashing Settings**

2. Click the Program Device icon  or go to **Run > Program Device**.
3. Power cycle the CertusPro NX versa board.

#### B.1.4. Programming the MCS File

To program MCS file in the SPI Flash in Radiant Programmer:

1. To program the MCS file, select the options as shown in [Figure B.13](#).
  - a. Under Programming Options, select the **soc\_golden\_system\_impl\_1.mcs** mcs file.
  - b. Make sure that the following addresses are correct:
    - **Start Address (Hex) – 0x00000000**
    - **End Address (Hex) – 0x007F0000**



**Figure B.13. Radiant Programmer - MCS Flashing Settings**

2. Click the Program Device icon  or go to **Run > Program Device**.
3. Power cycle the board the CertusPro NX versa board.

## B.2. Node System

This section provides the procedure for programming the SPI Flash on the Certus-NX Versa board for node. Two different files should be programmed into the SPI Flash. These files are programmed to the same SPI Flash, but at different addresses:

- Bitstream
- Binary

### Board Jumper Connections

Make sure that the following jumpers are connected on board:

- Pin 1 and 2 of JP25 and JP26 should be shorted to select UART.
- Pin 1 and 2 of J47 should be shorted to select the 1.8 V as Flash I/O.




Figure B.14. Node System Jumper Connection

To program the SPI Flash in Radiant Programmer:

1. Connect the Certus-NX Versa board to the PC using a USB cable.
2. Start Radiant Programmer. In the **Getting Started** dialog box, select **Create a new blank project**.




Figure B.15. Radiant Programmer - Default Screen (Node System)

3. Click **OK**.




Figure B.16. Radiant Programmer - Initial Project Window (Node System)

4. In the Radiant Programmer main interface, select **LFD2NX** for **Device Family** and **LFD2NX-40** for **Device** as shown in Figure B.17.




Figure B.17. Radiant Programmer - Device Properties (Node System)





Figure B.18. Radiant Programmer - Device Operation (Node System)

5. Before programming, apply the settings below to erase the flash memory:


- a. Under Device Operation, select the options below:
  - Target Memory – **External SPI Flash Memory (SPI FLASH)**
  - Port Interface – **JTAG2SPI**
  - Access Mode – **Direct Programming**
  - Operation – **Erase all**
- b. Under SPI Flash Options, select the options below:
  - Family – **SPI Serial Flash**
  - Vendor – **Micron**
  - Device – **MT25QU128**
  - Package – **8-pin SOP2**



**Figure B.19. Radiant Programmer - Erase All (Node System)**

6. Click **OK** and then click the Program Device icon  or go to **Run > Program Device**. This erases the flash memory if any other data is already present in it.
7. After erasing the flash, power cycle the board and apply the settings below:
  - a. Under Device Operation, select the options below:
    - Target Memory – **External SPI Flash Memory**
    - Port Interface – **SPI**
    - Access Mode – **Direct Programming**
    - Operation – **Erase, Program, Verify**
  - b. Under SPI Flash Options, select the options below:
    - Family – **SPI Serial Flash**
    - Vendor – **Micron**
    - Device – **MT25QU128**
    - Package – **8-pin SOP2**

8. To program the bitstream file, select the options as shown in [Figure B.20](#).




**Figure B.20. Radiant Programmer - Bit Stream Flashing Settings (Node System)**

- a. Under Programming Options, select the **soc\_node\_impl\_1.bit** bitstream file in the programming file.
  - b. Click Load from File to update the Data file size (Bytes) value.
  - c. Make sure that the following addresses are correct:
    - Start Address (Hex) – **0x00000000**
    - End Address (Hex) – **0x00100000**
9. Click the Program Device icon  or go to **Run > Program Device**.
10. To program the firmware, select the options as shown in [Figure B.21](#).
- a. Under Programming Options, select the **c\_node\_system\_2\_0.bin** binary file.
  - b. Make sure that the following addresses are correct:
    - Start Address (Hex) – **0x00140000**
    - End Address (Hex) – **0x00220000**



11. Click the **Program Device** icon  or go to Run > Program Device.



**Figure B.21. Radiant Programmer - Binary Flashing Settings (Node System)**

**Note:** After programming the Boards, power cycle the CertusPro NX Versa board as shown in [Figure B.22](#) and each Certus NX Versa board as shown in [Figure B.23](#), and press the system **Reset** button **SW3**.



**Figure B.22. Reset Button SW3 of CertusPro NX Versa Board**





**Figure B.23. Button SW3 of Certus NX Versa Board**

## Appendix C. Programming a Fresh Main System Board

If the user programming the Main System board for the first time, use the following one-time procedure to avoid the firmware booting issue. When the boards are delivered from the foundry, they are programmed in *Quad* mode. But the SPI Flash Controller starts with *Serial* mode (default) for commands and then it selects the quad mode for the read operation.

To program the SPI Flash in Quad mode:

1. Connect the CertusPro-NX Versa board to the PC using a USB cable.
2. Start Radiant Programmer. In the **Getting Started** dialog box, select **Create a new blank project**.




Figure C.1. Radiant Programmer - Default Screen

3. Click **OK**.




Figure C.2. Radiant Programmer - Initial Project Window

4. In the Radiant Programmer, select **LFCPNX** for **Device Family** and **LFCPNX-100** for **Device** or detect automatically as shown in Figure C.3.




Figure C.3. Radiant Programmer - Device Selection

5. Right-click and select **Device Properties**.






Figure C.4. Radiant Programmer - Device Operation

6. To program the binary file, apply the settings below:
  - a. Under Device Operation, select the options below:
    - Target Memory – **External SPI Flash Memory (SPI FLASH)**
    - Port Interface – **JTAG2SPI**
    - Access Mode – **Direct Programming**
    - Operation – **Erase, Program, Verify Quad 1**
  - b. Under SPI Flash Options, select the options below:
    - Family – **SPI Serial Flash**
    - Vendor – **Macronix**
    - Device – **MX25L51245G**
    - Package – **8-land WSON**




**Figure C.5. Radiant Programmer - Quad Mode Programming**

7. Under Programming Options, select the `c_main_system_3_1.bin` binary file.
  - a. Make sure that the following addresses are correct:
    - Start Address (Hex): **0x00300000**
    - End Address (Hex): **0x00380000**
8. Click **OK** and then click the Program Device icon  or the menu item **Run ->Program Device**. After that power cycle the board.
9. To program the bitstream file, select the options as shown in [Figure C.5](#).
10. Under Programming Options, select the `soc_main_system_impl_1.bit` bitstream file in the Programming file.



**Figure C.6. Radiant Programmer - Device Properties**

11. Click the Program Device icon  or go to **Run > Program Device**.
12. Apply the settings below to erase the SPI Flash:
  - a. Under Device Operation, select the options below:
    - Target Memory – **External SPI Flash Memory (SPI FLASH)**
    - Port Interface – **JTAG2SPI**
    - Access Mode – **Direct Programming**
    - Operation – **Erase All**
  - b. Under SPI Flash Options, select the options below:
    - Family – **SPI Serial Flash**
    - Vendor – **Macronix**
    - Device – **MX25L51245G**
    - Package – **8-land WSON**



**Figure C.7. Radiant Programmer - Erase All**

13. Click the Program Device icon  or go to **Run > Program Device**.
14. Power cycle the CertusPro NX Versa Board.

**Note:** This is a one-time process that must be followed for every new board.

## Appendix D. Checking Prints with MCS Manual and Automatic Booting

### D.1. Checking the Primary Main System Standalone Project Prints

To check the primary main system standalone project prints:

1. Connect the UART Cable between Host PC to CertusPro-NX Board.
2. Check the Status of UART Cable in Device Manager.
3. Go to the Port section of Device Manager.
4. Check Connection status is showing or not.
5. Program the following bitstream and binary files in the main system. To program the files, refer to [Appendix B. Programming the Automate Stack on Respective Flash](#).
  - a. Program the Primary Main System CRC binary file: `c_main_system_3_1_cnnCrc.bin`.
  - b. Program the Primary Main System bitstream file: `soc_main_system_3_1_impl_1.bit`.
6. After programming the Primary binary and bitstream file, check the log messages on the serial terminal.
7. Open the Propel terminal.
8. Double-click terminal button in the bottom of Propel SDK window as shown in [Figure D.1](#). The Launch Terminal window appears as shown in [Figure D.2](#).






Figure D.1. Open Propel Terminal



**Figure D.2. Propel Terminal Selection Window**

9. Choose terminal: Serial terminal as shown in [Figure D.3](#).
10. Select the right serial port, drop-down the serial port, and select the last COM.
11. Select the Baud rate **115200**.
12. Click **OK**.



**Figure D.3. Propel Terminal - Com and Baud Rate Selection**

13. If you are not receiving any packets, press the **SW3** reset button on the board or follow the below steps:
  - a. Press the Windows + R button simultaneously.
  - b. Type the command `ncpa.cpl` and press **Enter**.
  - c. Right-click on **Ethernet** and click **Disable**.
  - d. Right-click again and click **Enable**.
14. Wait for 40 seconds. The print is now available in the log section.



```

-----Primary Image Bootloader-----

DDR status = 30021

DDR status = 30021

DDR status = 3002f

DDR status = 3001f

LPDDR crc = d292
fw crc = d292
--- CRC matches-----
Main System Ready!

Automate Stack3.1 ver 0.1.0!
Version Date 01/04/2024
Node num 16, Node Data length 64
Before: Link Detected: 0
After: Link Detected: 15
Chain 1 Link for Main System detected
Node num 16, Node Data length 64
Org:detected_nodes 3
Chain : 1 ACTIVE NODE: 3
Org: 3
Chain : 1 FINAL ACTIVE NODE 3
node number 3
PHY LINK EXPECTED: f
BEFORE: TIMER PHY LINKS MAIN and NODES f
Node Num: 3
Before Node Enable: 1
After Node Enable: 7
Chain 1 nodes reg : 7
INIT_DONE
S1PSA1A2M2M3M5
  
```

Figure D.4. Primary Main System Propel Prints

15. Press the Reset SW3 button on the CertusPro NX Board to restart the prints.

## D.2. Checking the Golden Main System Standalone Project Prints

To check the golden main system standalone project prints:

1. Connect the UART Cable between Host PC to CertusPro-NX board.
2. Check the Status of UART Cable in Device Manager.
3. Go to the Port section of Device Manager.
4. Check Connection status is showing or not.
5. Program the Golden bitstream and binary files in the main system. To program the files, refer to [Appendix B. Programming the Automate Stack on Respective Flash](#).
  - a. Program the Golden Main System CRC binary file: **Golden\_AppCrc.bin**
  - b. Program the Golden Main System bitstream file: **soc\_main\_system\_impl\_1.bit**
6. After programming the Golden binary and bitstream file, follow the below steps to check the prints on propel terminal.
  - a. Open the Propel terminal. Refer to steps 8 to 16 of the [D.1. Checking the Primary Main System Standalone Project Prints](#) section. The print is available in the log section.
7. While waiting for ethernet packet, you need to send the packet sender udp\_rx command.
  - a. Open the packet sender tool.
  - b. In the top section, create a UDP packet.




Figure D.5. Packet Sender Application: Load file

- c. Provide name of packet, ASCII characters of the packet to be send, Address is 192.168.1.4 (main system address), port is 1486 as shown in Figure D.6.
- d. Click the **Send** button to send udp\_rx packet.




Figure D.6. Packet Sender Application: Send UDP Rx Packet

```

Problems Tasks Console Properties Terminal X
<Closed> COM10 X
-----Golden Image Bootloader-----

DDR status = 30021

DDR status = 30021

DDR status = 3002f

DDR status = 3001f

LPDDR crc = bd15      fw crc = bd15
                        --- CRC matches-----

-----Golden FW Image -----

FreeRTOS v10.0.1 on RISC-V.
the granularity of pmp is 4.
#####
pmp entry0: mode=0x01, perm=0x07, addr=0x2000266c(*4)=0x800099b0, locked=0
pmp entry1: mode=0x01, perm=0x00, addr=0x2000266d(*4)=0x800099b4, locked=1
pmp entry2: mode=0x01, perm=0x00, addr=0x20002670(*4)=0x800099c0, locked=0
pmp entry3: mode=0x01, perm=0x07, addr=0x3fffffff(*4)=0xffffffffc, locked=0
#####

-----Waiting for ethernet packet -----

-----Please make sure Ethernet cable is connected and link up done -----

S2MM status = 8000040

-----SGDMA packet received -----
44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645
-----SGDMA packet end -----

ARP REPLY DONE
      status = 8000040
#####

@ pmp test begin:
@ sstatus=0x00000100:
@ mstatus=0x00000180:

@ write/read secured region in task:

@ expectation(locked): write/read 0x800099b0 will fail
@ write/read 0x800099b0 begin, in=0x00001234
@ write/read 0x800099b0 done, out=0x00001234

@ expectation(m-mode): write/read 0x800099b4 will succeed
@ write/read 0x800099b4 begin, in=0x00005678
@ write/read 0x800099b4 done, out=0x00005678

@ write/read secured region with sys-call:

@ expectation: write/read 0x800099b4 will succeed
@ write/read 0x800099b4 begin, in=0x0000def0
@ write/read 0x800099b4 done, out=0x0000def0

```

Figure D.7. Golden Main System Propel Prints

- Press the **Reset** button on the CertusPro NX board to restart the prints.

## D.3. Checking the Main System Primary\_Golden MCS with Manual Booting Prints

- Connect the UART Cable between Host PC to CertusPro NX board.
- Check the Status of UART Cable in Device Manager.
- Go to the **Port** section of Device Manager.
- Check the connection status if it is showing or not.
- The following binaries and MCS are needed to be program, to program the files, refer to [Appendix B. Programming the Automate Stack on Respective Flash](#):
  - Program the Primary Main System CRC binary file: **Primary\_AppCrc.bin**
  - Program the Golden Main System CRC binary file: **Golden\_AppCrc.bin**
  - Program the MCS file. To generate the MCS file, refer to the Appendix D of the [Automate Stack 3.1 Reference Design \(FPGA-RD-02284\)](#).
- After programming the primary binary, golden binary, and MCS file, follow the steps below to check the prints on the Propel terminal.

- a. Open the Propel terminal. Refer to steps 8 to 16 of the [D.1. Checking the Primary Main System Standalone Project Prints](#) section.
  - b. Wait for 40 seconds for the primary system. The print is available in the log section.
7. To send the udp\_rx command for Golden System, refer to step 9 of the [D.2. Checking the Golden Main System Standalone Project Prints](#) section.

```

<Closed> COM10 X
-----Primary Image Bootloader-----

DDR status = 30021

DDR status = 30021

DDR status = 3002f

DDR status = 3001f

LPDDR crc = d292
      fw crc = d292
      --- CRC matches-----
Main System Ready!

Automate Stack3.1 ver 0.1.0!
Version Date 01/04/2024
Node num 16, Node Data length 64
Before: Link Detected: 0
After: Link Detected: 15
Chain 1 Link for Main System detected
Node num 16, Node Data length 64
Org:detected_nodes 3
Chain : 1 ACTIVE NODE: 3
Org: 3
Chain : 1 FINAL ACTIVE NODE 3
node number 3
PHY LINK EXPECTED: f
BEFORE: TIMER PHY LINKS MAIN and NODES f
Node Num: 3
Before Node Enable: 1
After Node Enable: 7
Chain 1 nodes reg : 7
INIT_DONE
S1PSA1A2M2M3M5
-----Golden Image Bootloader-----

DDR status = 30021

DDR status = 30021

DDR status = 3002f

DDR status = 3001f

LPDDR crc = bd15
      fw crc = bd15
      --- CRC matches-----

-----Golden FW Image -----

FreeRTOS v10.0.1 on RISC-V.
the granularity of pmp is 4.
#####
pmp entry0: mode=0x01, perm=0x07, addr=0x2000266c(*4)=0x800099b0, locked=0
pmp entry1: mode=0x01, perm=0x00, addr=0x2000266d(*4)=0x800099b4, locked=1
pmp entry2: mode=0x01, perm=0x00, addr=0x20002670(*4)=0x800099c0, locked=0
pmp entry3: mode=0x01, perm=0x07, addr=0x3fffffff(*4)=0xffffffffc, locked=0
#####

```

Figure D.8.Primary CRC Match Main System Propel Prints

```

Problems Tasks Console Properties Terminal X
<Closed> COM10 X

-----Golden FW Image -----
FreeRTOS v10.0.1 on RISC-V.
the granularity of pmp is 4.
#####
pmp entry0: mode=0x01, perm=0x07, addr=0x2000266c(*4)=0x800099b0, locked=0
pmp entry1: mode=0x01, perm=0x00, addr=0x2000266d(*4)=0x800099b4, locked=1
pmp entry2: mode=0x01, perm=0x00, addr=0x20002670(*4)=0x800099c0, locked=0
pmp entry3: mode=0x01, perm=0x07, addr=0x3fffffff(*4)=0xffffffffc, locked=0
#####

-----Waiting for ethernet packet -----
-----Please make sure Ethernet cable is connected and link up done -----

SZMM status = 80000040

-----SGDMA packet received -----
44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645
-----SGDMA packet end -----

ARP REPLY DONE
status = 80000040
#####
@ pmp test begin:
@ sstatus=0x00000100:
@ mstatus=0x00000188:

@ write/read secured region in task:
@ expectation(locked): write/read 0x800099b0 will fail
@ write/read 0x800099b0 begin, in=0x00001234
@ write/read 0x800099b0 done, out=0x00001234

@ expectation(m-mode): write/read 0x800099b4 will succeed
@ write/read 0x800099b4 begin, in=0x00005678
@ write/read 0x800099b4 done, out=0x00005678

@ write/read secured region with sys-call:
@ expectation: write/read 0x800099b4 will succeed
@ write/read 0x800099b4 begin, in=0x0000def0
@ write/read 0x800099b4 done, out=0x0000def0

@ pmp test end
#####
task 2147512688 is running, 0
task 2147510544 is running, 0
task 2147512688 is running, 1
task 2147510544 is running, 1
task 2147512688 is running, 2
task 2147510544 is running, 2
task 2147512688 is running, 3
suspend task 2147512688
task 2147510544 is running, 3
task 2147510544 is running, 4

```

Figure D.9. Golden CRC Match Main System Propel Prints

8. Press the Reset button on the CertusPro NX Board to restart the prints.
9. Press the SW2(program) button on the CertusPro NX Board to switch the prints.

## D.4. Check the Main System Primary\_Golden MCS with Automatic Booting Prints

1. Connect the UART Cable between Host PC to CertusPro NX Board.
2. Check the Status of UART Cable in Device Manager.
3. Go to the **Port** section of Device Manager.
4. Check the connection status if it is showing or not.
5. After programming the primary binary, golden binary, and MCS file, follow the below steps to check the prints on propel terminal.
  - a. The binaries and MCS files need to be programmed. To program the files, refer to [Appendix B. Programming the Automate Stack on Respective Flash](#).
  - b. Program the Primary Main System binary file: **Primary\_App.bin**
  - c. Program the Golden Main System CRC binary file: **Golden\_AppCrc.bin**
  - d. Program the MCS file. To generate the MCS file, refer to Appendix D of the [Automate Stack 3.1 Reference Design \(FPGA-RD-02284\)](#).
6. Open the Propel terminal. Refer to steps 8 to 16 of the [D.1. Checking the Primary Main System Standalone Project Prints](#) section.
7. The print is available in the log section.

8. To send the udp\_rx command for the Golden system, refer to step 9 of the [D.2. Checking the Golden Main System Standalone Project Prints](#) section.

```

Problems Tasks Console Properties Terminal X
<Closed> COM10 X
-----Primary Image Bootloader-----

DDR status = 30021
DDR status = 30021
DDR status = 3002f
DDR status = 3001f
LPDDR crc = 551
fw crc = ffff
--- CRC Mis-matched!!!-----y
-----Golden Image Bootloader-----

DDR status = 30021
DDR status = 30021
DDR status = 3002f
DDR status = 3001f
LPDDR crc = bd15
fw crc = bd15
--- CRC matches-----

-----Golden FW Image -----
FreeRTOS v10.0.1 on RISC-V.
the granularity of pmp is 4.
#####
pmp entry0: mode=0x01, perm=0x07, addr=0x2000266c(*4)=0x800099b0, locked=0
pmp entry1: mode=0x01, perm=0x00, addr=0x2000266d(*4)=0x800099b4, locked=1
pmp entry2: mode=0x01, perm=0x00, addr=0x20002670(*4)=0x800099c0, locked=0
pmp entry3: mode=0x01, perm=0x07, addr=0x3fffffff(*4)=0xffffffffc, locked=0
#####
-----Waiting for ethernet packet -----
-----Please make sure Ethernet cable is connected and link up done -----
S2MM status = 80000040
-----SGDMA packet recived -----
44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645
-----SGDMA packet end -----
ARP REPLY DONE
status = 80000040
#####
@ pmp test begin:
@ sstatus=0x00000100:
@ mstatus=0x00000188:
@ write/read secured region in task:
@ expectation(locked): write/read 0x800099b0 will fail

```

**Figure D.10. Primary CRC Mismatch Main System Propel Prints**

```

Problems Tasks Console Properties Terminal X
<Closed> COM10 X
-----Golden FW Image -----

FreeRTOS v10.0.1 on RISC-V.
the granularity of pmp is 4.
#####
pmp entry0: mode=0x01, perm=0x07, addr=0x2000266c(*4)=0x800099b0, locked=0
pmp entry1: mode=0x01, perm=0x00, addr=0x2000266d(*4)=0x800099b4, locked=1
pmp entry2: mode=0x01, perm=0x00, addr=0x20002670(*4)=0x800099c0, locked=0
pmp entry3: mode=0x01, perm=0x07, addr=0x3fffffff(*4)=0xffffffffc, locked=0
#####

-----Waiting for ethernet packet -----

-----Please make sure Ethernet cable is connected and link up done -----

S2MM status = 80000040

-----SGDMA packet received -----
44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645 44434241 48474645
-----SGDMA packet end -----

ARP REPLY DONE
status = 80000040
#####
@ pmp test begin:
@ sstatus=0x00000100:
@ mstatus=0x00000188:

@ write/read secured region in task:

@ expectation(locked): write/read 0x800099b0 will fail
@ write/read 0x800099b0 begin, in=0x00001234
@ write/read 0x800099b0 done, out=0x00001234

@ expectation(m-mode): write/read 0x800099b4 will succeed
@ write/read 0x800099b4 begin, in=0x00005678
@ write/read 0x800099b4 done, out=0x00005678

@ write/read secured region with sys-call:

@ expectation: write/read 0x800099b4 will succeed
@ write/read 0x800099b4 begin, in=0x0000def0
@ write/read 0x800099b4 done, out=0x0000def0

@ pmp test end
#####
task 2147512688 is running, 0
task 2147510544 is running, 0
task 2147512688 is running, 1
task 2147510544 is running, 1
task 2147512688 is running, 2
task 2147510544 is running, 2
task 2147512688 is running, 3
suspend task 2147512688
task 2147510544 is running, 3
task 2147510544 is running, 4
task 2147510544 is running, 5

```

Figure D.11. Golden CRC Match Main System Propel Prints

9. Press the Reset button on the CertusPro NX Board to restart the prints.
10. Press the **SW2** (program) button on the CertusPro NX Board to switch the prints.

## D.5 Checking the Main System Primary\_Golden MCS with Automatic Booting Prints

1. Connect the UART Cable between Host PC to CertusPro NX board.
2. Check the Status of UART Cable in Device Manager.
3. Go to the Port section of Device Manager.
4. Check Connection status is showing or not.
5. After programming the Primary binary, golden binary, and MCS file, follow the below steps to check the prints on propel terminal.
  - a. The binaries and MCS files need to be programmed. To program the files, refer to [Appendix B. Programming the Automate Stack on Respective Flash](#).
  - b. Program the Primary Main System CRC binary file: **Primary\_AppCrc.bin**
  - c. Program the Golden Main System binary file: **Golden\_App.bin**
  - d. Program the MCS file. To generate the MCS file, refer to Appendix D of the [Automate Stack 3.1 Reference Design \(FPGA-RD-02284\)](#).

6. Open the Propel terminal. Refer to steps 8 to 16 of the [D.1. Checking the Primary Main System Standalone Project Prints](#) section.
7. Wait for 40 seconds for the primary system. The print is available in the log section.



```

COM10 X
-----Primary Image Bootloader-----


DDR status = 30021
DDR status = 30021
DDR status = 3002f
DDR status = 3001f
LPDDR crc = d292
fw crc = d292
--- CRC matches-----
Main System Ready!

Automate Stack3.1 ver 0.1.0!
Version Date 01/04/2024
Node num 16, Node Data length 64
Before: Link Detected: 0
After: Link Detected: 15
Chain 1 Link for Main System detected
Node num 16, Node Data length 64
Org:detected_nodes 3
Chain : 1 ACTIVE NODE: 3
Org: 3
Chain : 1 FINAL ACTIVE NODE 3
node number 3
PHY LINK EXPECTED: f
BEFORE: TIMER PHY LINKS MAIN and NODES f
Node Num: 3
Before Node Enable: 1
After Node Enable: 7
Chain 1 nodes reg : 7
INIT_DONE
S1PSA1A2M2M3M5
-----Golden Image Bootloader-----

DDR status = 30021
DDR status = 30021
DDR status = 3002f
DDR status = 3001f
LPDDR crc = bd15
fw crc = ffff
--- CRC Mis-matched!!!-----

```

**Figure D.12.Primary CRC Match Main System Propel Prints**



```

-----Golden Image Bootloader-----

DDR status = 30021
DDR status = 30021
DDR status = 3002f
DDR status = 3001f
LPDDR crc = bd15
fw crc = ffff
--- CRC Mis-matched!!!-----

```

**Figure D.13.Golden CRC Mismatch Main System Propel Prints**

8. Press the **Reset** button on the CertusPro NX Board to restart the prints.
9. Press the **SW2** (program) button on the CertusPro NX board to switch the prints.



## Appendix E. Ethernet Connection

### E.1. Connection Between Main system and Laptop/PC

To connect the main system and PC:


- Set up the following hardware connections, as shown in [Figure E.1](#):
  - Connect the Ethernet cable between the CertusPro-NX board and the Laptop/PC in the Ethernet port of the laptop and main system.
  - Connect the 12 V power adapter to the main system board.
- Connect the UART cable to the main board and laptop or Docklight debugging.

**Notes:**

- The firewall must be disabled while doing this activity.
- .bit and .bin must be programmed in the main system and node systems. Refer to [Programming the Automate Stack on Respective FLASH](#) and [Programming a Fresh Main System Board](#) sections.


### E.2. Ethernet Configuration Setting

- Open the Network Connections Control Panel from the Start menu or by pressing Windows+R and typing ncpa.cpl.




**Figure E.1. Run the ncpa.cpl to Open the Network Connections Control Panel**

- Click **Ethernet**.




**Figure E.2. Ethernet Settings**

- Click **Properties**.



**Figure E.3. Ethernet Status – Properties Window**


4. Double-click on **Internet Protocol Version**.



**Figure E.4. Ethernet Properties – Internet Protocol Version Window**


- Configure the IP address, subnet mask, and default gateway settings as shown in [Figure E.5](#). Click **OK**.

**Note:** If you change the IP address of the PC using Propel Builder, make sure to enter the changed IP address in TCP/IPv4 settings. For more information on how to change the IP addresses of the PC, see section 2.6 of the [Automate Stack 3.1 Reference Design \(FPGA-RD-02284\)](#).



**Figure E.5. Configure the Settings**

- Check if Ethernet says *Network cable unplugged*.
- Right-click on **Ethernet** and select **Disable**.



**Figure E.6. Disable the Setting**

- Right-click on the **Ethernet** and click **Enable**.




Figure E.7. Enable the Setting

**Note:** Steps 8 and 9 are required every time the Ethernet cable is disconnected or inserted, or when the main system is power cycled.

### E.3. Check the Connection with a Ping

1. Open the command prompt on the PC.
2. Ping the main board using the command: **ping 192.168.1.4**.
3. Make sure the ping is successful. Otherwise, follow the steps in the [Connection Between Main system and Laptop/PC](#) and [Ethernet Configuration Setting](#) sections again.

```
C:\Users\Pawan>ping 192.168.1.4

Pinging 192.168.1.4 with 32 bytes of data:
Request timed out.
Reply from 192.168.1.4: bytes=32 time<1ms TTL=128
Reply from 192.168.1.4: bytes=32 time<1ms TTL=128
Reply from 192.168.1.4: bytes=32 time<1ms TTL=128

Ping statistics for 192.168.1.4:
    Packets: Sent = 4, Received = 3, Lost = 1 (25% loss),
    Approximate round trip times in milli-seconds:
        Minimum = 0ms, Maximum = 0ms, Average = 0ms

C:\Users\Pawan>
```

Figure E.8. Ping on cmd Terminal

### E.4. UDP Packet Transaction

**Note:** To download the wireshark tool: <https://www.wireshark.org/download.html>

Wireshark and packet sender both are used for debugging. The packet Sender creates its own payload packets and transmits. Wireshark receives packets and the user can check the data (payload), IP address, and port number.

Packet Sender is also used separately for debugging where you can send multiple commands and check the functionality of the main system.

## Download Wireshark

The current stable release of Wireshark is 4.0.3. It supersedes all previous releases.




Figure E.9. Wireshark Downloadable Link

**Note:** To download the Packet Sender tool: <https://packetsender.com/download>




Figure E.10. Packet Sender Downloadable Link

To start the UDP packet transaction using Docklight:

1. Open **Docklight**.
2. Go to **COM**.




Figure E.11. Docklight - Com Selection

3. Select the right COM port, drop-down the COM and select the last COM.
4. Set the baud rate: **9600**.
5. Click **OK**.




Figure E.12. Docklight - Com and Baud Rate Selection

6. Click **Run**.




Figure E.13. Docklight - Run (Start Communication)

7. Open the Wireshark tool.
8. Click **Ethernet**.




Figure E.14. Wireshark Tool - Ethernet Selection

9. Click on the Run (  ) icon.
10. Open the **Packet Sender** tool.
11. Enter 64 ASCII characters for a total of 64 bytes of data. For example, enter abcdefgh eight times.

12. Click **Save**.



Figure E.15. Packet Sender Tool - Send 64 Bytes of ASCII Characters

13. Click **Send** to send the UDP\_PK packet.

|    | Send | Name                      | Resend | To Address       | To Port | Method | ASCII                      |                        |
|----|------|---------------------------|--------|------------------|---------|--------|----------------------------|------------------------|
| 20 | Send | TCP-HTTP packetsender.com | 0      | packetsender.com | 80      | TCP    | GET / HTTP/1.0\r\n\r\n     | 47 45 54 20 2f 20 48 5 |
| 21 | Send | Telnet RPG                | 0      | avalon-rpg.com   | 23      | TCP    |                            |                        |
| 22 | Send | UDP Broadcast             | 0      | 255.255.255.255  | 5000    | UDP    | Hello, broadcast!          | 48 65 6c 6c 6f 2c 20 6 |
| 23 | Send | UDP IPv4 localhost macro  | 0      | 127.0.0.1        | 5000    | UDP    | {{TIME}} {{RANDOM}}        | 7b 7b 54 49 4d 45 7d   |
| 24 | Send | UDP IPv6 localhost macro  | 0      | ::1              | 5000    | UDP    | {{TIME}} {{RANDOM}}        | 7b 7b 54 49 4d 45 7d   |
| 25 | Send | UDP Multicast             | 0      | 224.0.0.51       | 5000    | UDP    | hello!r                    | 68 65 6c 6c 6f 0d      |
| 26 | Send | UDP_PK                    | 0      | 192.168.1.4      | 1486    | UDP    | abcdefghijklmnopqrstuvwxyz | 61 62 63 64 65 66 67 6 |
| 27 | Send | Send UDP_PK .ie.com       | 0      | 192.34.234.30    | 43      | TCP    | domain.google.com\r\n      | 64 6f 6d 61 69 6e 20 6 |

Figure E.16. Packet Sender Tool - Send UDP Packet

14. Check the log.

| Time         | From IP | From Port | To Address  | To Port | Method | Error | ASCII                                                                                                                                              | Hex |
|--------------|---------|-----------|-------------|---------|--------|-------|----------------------------------------------------------------------------------------------------------------------------------------------------|-----|
| 14:26:01.187 | You     | 53599     | 192.168.1.4 | 1486    | UDP    |       | abcdefghijklmnopqrstuvwxyz 61 62 63 64 65 66 67 68 61 62 63 64 65 66 67 68 61 62 63 64 65 66 67 68 61 62 63 64 65 66 67 68 61 62 63 64 65 66 67 68 |     |

Figure E.17. Packet Sender Tool - Transaction Log

15. Open Docklight to check the data received.

16. Check if the UDP data is received.

| ASCII                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                 | HEX | Decimal | Binary |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|---------|--------|
| <pre> 01-02-2023 14:26:01.196 [RX] - Packetlength = 40 &lt;CR&gt;&lt;LF&gt; Value of size = 40 &lt;CR&gt;&lt;LF&gt; Value of res_size = 40 &lt;CR&gt;&lt;LF&gt; &lt;LF&gt; UDP data received ----- Start&lt;LF&gt; 616263646566676861626364656667686162636465666768616263646566676861626364656667686162636465666768&lt;LF&gt; UDP data received -----End&lt;LF&gt; &lt;LF&gt; Unknown cmd : 64636261&lt;LF&gt; Value of ConVAL = 40 &lt;CR&gt;&lt;LF&gt; Value of ConVAL = 40 &lt;CR&gt;&lt;LF&gt; &lt;LF&gt; Waiting for new packet&lt;LF&gt; </pre> |     |         |        |

Figure E.18. Docklight - Logs in ASCII

17. Go to the Wireshark tool.

18. Type **udp.port == 1486** on top of the bar, as shown in [Figure E.19](#).

| udp.port == 1486 |          |             |             |          |        |                     |
|------------------|----------|-------------|-------------|----------|--------|---------------------|
| No.              | Time     | Source      | Destination | Protocol | Length | Info                |
| 8                | 6.638453 | 192.168.1.2 | 192.168.1.4 | UDP      | 106    | 53599 → 1486 Len=64 |

|                                                                                                                                                                                  |  |  |  |  |  |  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|--|--|--|
| > Frame 8: 106 bytes on wire (848 bits), 106 bytes captured (848 bits) on interface \Device\NPF_{5E299B74-0000-aa cd ef 12 34 56 50 81 40 7e 83 a9 08 00 45 00} ...4VP- @-...-E- |  |  |  |  |  |  |
| > Ethernet II, Src: HP_7e:83:a9 (50:81:40:7e:83:a9), Dst: aa:cd:ef:12:34:56 (aa:cd:ef:12:34:56)                                                                                  |  |  |  |  |  |  |
| > Internet Protocol Version 4, Src: 192.168.1.2, Dst: 192.168.1.4                                                                                                                |  |  |  |  |  |  |
| > User Datagram Protocol, Src Port: 53599, Dst Port: 1486                                                                                                                        |  |  |  |  |  |  |
| > Data (64 bytes)                                                                                                                                                                |  |  |  |  |  |  |

|      |                         |                         |                   |
|------|-------------------------|-------------------------|-------------------|
| 0000 | aa cd ef 12 34 56 50 81 | 40 7e 83 a9 08 00 45 00 | ....4VP- @-...-E- |
| 0010 | 00 5c 84 f5 00 00 80 11 | 00 00 c0 a8 01 02 c0 a8 | ..-...-H ..abcdef |
| 0020 | 01 04 d1 5f 05 ce 00 48 | 83 b0 61 62 63 64 65 66 | .....H ..abcdef   |
| 0030 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0040 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0050 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0060 | 67 68 61 62 63 64 65 66 | 67 68                   | ghabcdef gh       |

Figure E.19. Wireshark Tool - Write udp.port == 1486

19. Check both the Source and Destination UDP packets.

| udp     |          |             |             |          |        |                     |
|---------|----------|-------------|-------------|----------|--------|---------------------|
| No.     | Time     | Source      | Destination | Protocol | Length | Info                |
| 2690... | 6.993534 | 192.168.1.2 | 192.168.1.4 | UDP      | 106    | 53599 → 1486 Len=64 |
| 2691... | 7.305692 | 192.168.1.4 | 192.168.1.2 | UDP      | 106    | 1500 → 1482 Len=64  |

Figure E.20. Source and Destination UDP Packet

20. Click the first UDP transaction to check in detail.

| udp     |          |             |             |          |        |                     |
|---------|----------|-------------|-------------|----------|--------|---------------------|
| No.     | Time     | Source      | Destination | Protocol | Length | Info                |
| 2690... | 6.993534 | 192.168.1.2 | 192.168.1.4 | UDP      | 106    | 53599 → 1486 Len=64 |
| 2691... | 7.305692 | 192.168.1.4 | 192.168.1.2 | UDP      | 106    | 1500 → 1482 Len=64  |

|                                                                                                                                                                                        |  |  |  |  |  |  |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|--|--|--|
| > Frame 2690840: 106 bytes on wire (848 bits), 106 bytes captured (848 bits) on interface \Device\NPF_{5E299B74-0000-aa cd ef 12 34 56 50 81 40 7e 83 a9 08 00 45 00} ...4VP- @-...-E- |  |  |  |  |  |  |
| > Ethernet II, Src: HP_7e:83:a9 (50:81:40:7e:83:a9), Dst: aa:cd:ef:12:34:56 (aa:cd:ef:12:34:56)                                                                                        |  |  |  |  |  |  |
| > Internet Protocol Version 4, Src: 192.168.1.2, Dst: 192.168.1.4                                                                                                                      |  |  |  |  |  |  |
| > User Datagram Protocol, Src Port: 53599, Dst Port: 1486                                                                                                                              |  |  |  |  |  |  |
| > Data (64 bytes)                                                                                                                                                                      |  |  |  |  |  |  |

|      |                         |                         |                   |
|------|-------------------------|-------------------------|-------------------|
| 0000 | aa cd ef 12 34 56 50 81 | 40 7e 83 a9 08 00 45 00 | ....4VP- @-...-E- |
| 0010 | 00 5c 85 02 00 00 80 11 | 00 00 c0 a8 01 02 c0 a8 | ..-...-H ..abcdef |
| 0020 | 01 04 d1 5f 05 ce 00 48 | 83 b0 61 62 63 64 65 66 | .....H ..abcdef   |
| 0030 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0040 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0050 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0060 | 67 68 61 62 63 64 65 66 | 67 68                   | ghabcdef gh       |

Figure E.21. Wireshark Tool - First UDP Packet

21. Click the second UDP transaction to check in detail.

| udp     |          |             |             |          |        |                     |
|---------|----------|-------------|-------------|----------|--------|---------------------|
| No.     | Time     | Source      | Destination | Protocol | Length | Info                |
| 2690... | 6.993534 | 192.168.1.2 | 192.168.1.4 | UDP      | 106    | 53599 → 1486 Len=64 |
| 2691... | 7.305692 | 192.168.1.4 | 192.168.1.2 | UDP      | 106    | 1500 → 1482 Len=64  |

|                                                                                                                                                                                       |  |  |  |  |  |  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|--|--|--|--|--|
| > Frame 2691430: 106 bytes on wire (848 bits), 106 bytes captured (848 bits) on interface \Device\NPF_{5E299B74-0000-50 81 40 7e 83 a9 aa cd ef 12 34 56 08 00 45 00} P-@-...-4V-..E- |  |  |  |  |  |  |
| > Ethernet II, Src: aa:cd:ef:12:34:56 (aa:cd:ef:12:34:56), Dst: HP_7e:83:a9 (50:81:40:7e:83:a9)                                                                                       |  |  |  |  |  |  |
| > Internet Protocol Version 4, Src: 192.168.1.4, Dst: 192.168.1.2                                                                                                                     |  |  |  |  |  |  |
| > User Datagram Protocol, Src Port: 1500, Dst Port: 1482                                                                                                                              |  |  |  |  |  |  |
| > Data (64 bytes)                                                                                                                                                                     |  |  |  |  |  |  |

|      |                         |                         |                   |
|------|-------------------------|-------------------------|-------------------|
| 0000 | 50 81 40 7e 83 a9 aa cd | ef 12 34 56 08 00 45 00 | P-@-...-4V-..E-   |
| 0010 | 00 5c 00 11 40 00 40 11 | b7 29 c0 a8 01 04 c0 a8 | ..-...-H ..abcdef |
| 0020 | 01 02 05 dc 05 ca 00 48 | e3 b4 61 62 63 64 65 66 | .....H ..abcdef   |
| 0030 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0040 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0050 | 67 68 61 62 63 64 65 66 | 67 68 61 62 63 64 65 66 | ghabcdef ghabcdef |
| 0060 | 67 68 61 62 63 64 65 66 | 67 68                   | ghabcdef gh       |

Figure E.22. Wireshark Tool - Second UDP Packet



## E.5. Packet Sender Commands

### E.5.1. Motor Config Commands

#### Update Config

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 05 00 00 00 02  
00 00 00 07 00 00 00 af 96 04 96 a0 0f 15 26 80 00 40 00 10 00 00 08 80 00 40 00 fa  
00 00 08 00 00 00 00 00 00 00 00
```

#### TestNodeReg\_Write\_led\_OFF

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 e3 10 e4 31 bf 1d e4 2f d9 00 ff ff ff 0f 00  
01 00 00 54 40 18 00 ff ff ff ff 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00
```

#### TestNodeReg\_Write\_led\_ON

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 e3 10 e4 31 bf 1d e4 2f d9 00 ff ff ff 0f 00  
01 00 00 54 40 18 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00
```

#### StartMotor\_dashboard

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 12 00 00 00 02  
00 00 00 07 00 00 00 78 00 01 00 78 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00
```

#### StopMotor\_dashboard

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 02 00 00 00 02  
00 00 00 07 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00
```

#### PowerOffMotor\_dashboard

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 03 00 00 00 02  
00 00 00 07 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00
```

#### MotorStart\_MotorStatusTab

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 01 00 00 00 02  
00 00 00 01 00 00 00 78 00 00 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00
```

#### MotorStop\_MotorStatusTab

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 02 00 00 00 02  
00 00 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00
```

#### PowerOffMotor\_StatusTab

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 03 00 00 00 02  
00 00 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00
```

#### Motor\_rpm\_500\_MotorStatusTab

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 01 00 00 00 02  
00 00 00 01 00 00 00 f4 01 00 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00 00
```

#### Motor\_rpm\_1000\_MotorStatusTab

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 01 00 00 00 02  
00 00 00 01 00 00 00 e8 03 00 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00 00
```

#### Motor\_rpm\_1400\_MotorStatusTab

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 01 00 00 00 02  
00 00 00 01 00 00 00 78 05 00 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00 00
```

#### Motor\_rpm\_1800\_MotorStatusTab

```
hexString=f1 01 77 cc 01 64 00 01 4d f4 63 ea 37 18 1e 7c 37 18 1e 00 01 00 00 00 02  
00 00 00 01 00 00 00 08 07 00 00 01 00 00 00 00 00 00 00 00 00 00 00 00 00  
00 00 00 00 00 00 00 00 00 00 00 00 00
```

**Note:** To select a different node, change the highlighted bit in Motor Start Motor status command.

- 01 – First node
- 02 – Second node
- 04 – Third node and so on
- 07 – All Nodes

### E.5.2. Recommend Command Sequences to Test Basic Functionality

#### Basic LED OFF/ON Command

- Send LED OFF Command
- Send LED ON command

#### Motor Config Test

- Send the Update config command

#### Motor Start from Dashboard Test

- Send the start motor dashboard command
- Send the Motor RPM 500 Motor Status command
- Send the Motor RPM 1000 Motor Status command
- Send the Motor RPM 1400 Motor Status command
- Send the Motor RPM 1800 Motor Status command
- Send the Stop motor dashboard command
- Send the Power Off motor dashboard command

#### Motor start from Motor Status Test

- Send the Motor Start Motor status command
- Send the Motor RPM 500 Motor Status command
- Send the Motor RPM 1000 Motor Status command
- Send the Motor RPM 1400 Motor Status command
- Send the Motor RPM 1800 Motor Status command
- Send the Motor Stop Motor status command
- Send the Power Off Motor Status command

## Appendix F. Troubleshooting

### F.1. Automate 3.1 User Interface Troubleshooting

#### F.1.1. Motor Configuration Values are 0

##### Problem Description:

Motor configuration values are all 0.




Figure F.1. Motor Configuration Values are All 0

##### Solution:

1. In the Automate 3.1 user interface, click the **Motor Configuration** tab.
2. From the Select drop-down menu, either Select **All** or select an individual node.

The screenshot shows the 'Motor Configuration' tab in the Automate Stack 3.1 Demo application. The 'Node Selection' dropdown menu is open, showing options: 'Select All', 'Node1', 'Node2', 'Node9', and 'Node10'. The 'Number of Poles' is set to 2 - 64. The 'RPM PI Control Prop. Gain (kP)' is 1 - 65535. The 'Torque PI Control Prop. Gain (kP)' is 1 - 65535. The 'Maximum RPM' is 1 - 65535. The 'RPM PI Int. Gain (kI)' is 1 - 65535. The 'Torque PI Int. Gain (kI)' is 1 - 65535. The 'Minimum Power' is 1 - 255. The 'RPM PI Int. Threshold' is 1 - 65535. The 'Torque PI Int. Threshold' is 1 - 65535. The 'Power Gain' is 1 - 255. The 'RPM PI Int. Clamp' is 1 - 65535. The 'Torque PI Int. Clamp' is 1 - 65535. The 'Breaker Amps' is 0.1 - 9.9. The 'RPM PI Control Delay' is 1 - 255. The 'Torque PI Control Delay' is 1 - 255. The 'Default', 'Update', and 'Save' buttons are at the bottom. A 'Stop' button is in the bottom right corner.

Figure F.2. Motor Configuration: Node Selection

The screenshot shows the 'Motor Configuration' tab in the Automate Stack 3.1 Demo application. The 'Node Selection' dropdown menu is set to 'Node1, Node2, Node9, Node10'. The 'Number of Poles' is 4. The 'RPM PI Control Prop. Gain (kP)' is 128. The 'Torque PI Control Prop. Gain (kP)' is 128. The 'Maximum RPM' is 4000. The 'RPM PI Int. Gain (kI)' is 16. The 'Torque PI Int. Gain (kI)' is 250. The 'Minimum Power' is 175. The 'RPM PI Int. Threshold' is 64. The 'Torque PI Int. Threshold' is 64. The 'Power Gain' is 21. The 'RPM PI Int. Clamp' is 2048. The 'Torque PI Int. Clamp' is 2048. The 'Breaker Amps' is 1.5. The 'RPM PI Control Delay' is 150. The 'Torque PI Control Delay' is 150. The 'Default', 'Update', and 'Save' buttons are at the bottom. A 'Stop' button is in the bottom right corner.

Figure F.3. Motor Configuration: All Nodes Selected

3. Change the Motor Configuration fields to the following default values:

- RPI PI Control Prop. Gain(kP): **90**
- RPI PI Int. Gain(kI): **10**
- RPI PI Control delay: **200**
- Minimum Power: **190 - 200**
- Power gain: **22 - 24**
- Breaker Amps: **1.8 - 2.0**

**Note:** These values are for the GB-42 BLS 24 V, 5000 RPM motors only. Choose appropriate values for the motors that you are using.

The screenshot shows the 'Motor Configuration' tab in the application software. The interface is divided into several sections for configuring motor parameters. The 'Number of Poles' is set to 4, 'Maximum RPM' is 4000, 'Minimum Power' is 195, 'Power Gain' is 23, and 'Breaker Amps' is 1.9. The 'RPM PI Control' section includes 'Prop. Gain (kP)' at 90, 'Int. Gain (kI)' at 10, 'Int. Threshold' at 64, 'Int. Clamp' at 2048, and 'Control Delay' at 200. The 'Torque PI Control' section includes 'Prop. Gain (kP)' at 128, 'Int. Gain (kI)' at 250, 'Int. Threshold' at 64, 'Int. Clamp' at 2048, and 'Control Delay' at 150. At the bottom, there are buttons for 'Default', 'Update', 'Save', and 'Stop'.

Figure F.4. Motor Configuration Value Changes

4. Click **Default**.
5. Click **Update**.
6. Click **Yes** on the Pop-up confirmation message.




Figure F.5. Application Software - Motor Configuration: Warning Message

7. Enter the Credentials in the authentication pop-up and click on **Login**.
  - **Username:** lattice
  - **Password:** lattice



Figure F.6. Application Software - Motor Configuration: Authentication Pop-up

8. Click **OK** on the pop-up message stating that successfully updated the configuration of the selected node appears.




Figure F.7. Application Software - Motor Configuration: Update Configuration

- If a success pop-up message does not appear, or if a message appears stating that it failed to configure the node, restart the system.

### F.1.2. Motor Status Tab Failure (RPM Lock Status, Voltage Status and Drive Status are Red)

**Problem Description:** The motor cannot be stopped from the user interface, and/or RPM Lock Status, Voltage Status, and Drive Status indicators are red, as shown in Figure F.8.

**Solution:** Power everything off and restart the setup.




Figure F.8. Application Software- Motor Status Tab: Red Status

### F.1.3. One of the Selected Motor Running Warning

**Problem Description:** The pop-up message *One of the selected motors is running* appears.




Figure F.9. Motor Running Warning Message

**Solution:** Stop all the motors, then configure or update the Motor Configuration.

### F.1.4. Did not Receive Response from the Board Warning

#### Problem Description:

The pop-up message **Did not receive response from the board** appears while connecting to the user interface.




Figure F.10. Motor Connection Message

#### Solution:

1. Check the Ethernet connection. Follow the steps in [Appendix E. Ethernet Connection](#)
2. to ping the main board from the PC.
3. Make sure the Main System Ready and Node System Ready LEDs are illuminated, as described in the [Hardware System Readiness](#) section.
4. Use Docklight to check the print statements from the main board:
  - a. Connect a UART cable between the Main Board and a PC with Docklight installed.
  - b. Open Docklight on the PC.
  - c. Double-click **COM**.




Figure F.11. Motor Connection Message

- d. Select the last USB serial port in the list, as shown in [Figure F.12](#).




Figure F.12. Send/Receive on Comm. Channel

- e. Select baud rate **9600**.




Figure F.13. Project Settings

- f. Click **Run**.



Figure F.14. Run Button

- g. Power cycle the Main Board or press **SW3** button on the Main Board.  
h. In Docklight, select the **ASCII** tab. Wait 60 seconds and check that the print statements are valid, as shown in Figure F.15.




Figure F.15. ASCII Print Statements



- i. LED D64 on the Main Board should be illuminated after the Docklight prints have appeared.
- j. If LED D64 did not illuminate and/or the Docklight prints are incorrect, power cycle the Main System.
5. Check the IP address on the user interface.
  - a. Make sure the Automate 3.1 user interface is set to connect to IP address **192.168.1.4**.




Figure F.16. Automate 3.1 User Interface

- b. If you change the main system's IP address in Propel Builder, make sure using the changed IP address. Refer to section 2.6 of the [Automate Stack 3.1 Reference Design \(FPGA-RD-02284\)](#) document for more details on changing the main system's IP address.

### F.1.5. Allowing Permission to Publisher and Subscriber

#### Problem Description:

You skipped the *allow the permission* while installing the Automate 3.1 user application and throw this message on the user interface: *Did not receive response from the board (Not able to load)*.

#### Solution:

1. Complete the installation steps.
2. Open the user interface.
3. Click **Connect**.
4. Allow permission to the subscriber.




Figure F.17. Allow Permission: Subscriber

5. Allow the permission to publisher. Another way is to changes the directory location.



**Figure F.18. Allow Permission: Publisher**

## Annexure-A

### Cable Description

| Sl. No. | Cable                                                                                                                             | Description                                                                                                       |
|---------|-----------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| 1       | <p>Mini USB</p>                                  | It is used to interface the Mini USB port of the board to the PC for the purpose of loading .bit file and Modbus. |
| 2       | <p>Aardvark I<sup>2</sup>C/SPI Host Adapter</p>  | It is used to interface between PC and Lattice Certus NX Board through I2C and SPI protocol.                      |
| 3       | <p>FS SFP-GB-GE-T</p>                           | It is used to make an Ethernet connection on the main system board                                                |

## References

- [CertusPro-NX](#) web page
- [Certus-NX](#) web page
- [Lattice Automate](#)

Other references:

- [Lattice Insights](#) for Lattice Semiconductor training courses and learning plans
- [Lattice Radiant](#) FPGA design software

## Technical Support Assistance

Submit a technical support case through [www.latticesemi.com/techsupport](http://www.latticesemi.com/techsupport).

For frequently asked questions, refer to the Lattice Answer Database at [www.latticesemi.com/Support/AnswerDatabase](http://www.latticesemi.com/Support/AnswerDatabase).

## Revision History

### Revision 1.1, February 2024

| Section                                                           | Change Summary                                                                                                                                                                                                                                                     |
|-------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Automate Stack File Directory Structure                           | Updated the <a href="#">Main System</a> content.                                                                                                                                                                                                                   |
| Appendix B. Programming the Automate Stack on Respective Flash    | Added the following sections: <ul style="list-style-type: none"><li><a href="#">B.1.1. Programming NV Register – Enabling 32-bit SPI Addressing</a></li><li><a href="#">B.1.2. Primary Main System</a></li><li><a href="#">B.1.3. Golden Main System</a></li></ul> |
| Appendix D. Checking Prints with MCS Manual and Automatic Booting | Newly added section.                                                                                                                                                                                                                                               |

### Revision 1.0, December 2023

| Section | Change Summary   |
|---------|------------------|
| All     | Initial release. |



[www.latticesemi.com](http://www.latticesemi.com)