

This document provides a brief introduction to the Lattice ORAN Timing and Synchronization Kit.









# Lattice ORAN Timing and Synchronization Kit



## **Check Kit Contents**

The Lattice ORAN Timing and Synchronization Kit contains the following items:

- 1x EVK Mother board
- 1x EVK Daughter board
- 1x Mini-USB to USB-A cable (to flash the firmware and connect the EVK to GUI application on Linux)
- 2x SFP module for the 10G Ethernet
- 2x Fiber Optic cables with 3m length (to connect the EVK over 10G Ethernet)
- GNSS Antenna
- 1x PCIe cable (to connect the EVK PCIe edge connector to a PCIe slot on Linux PC)
- 1x 230 V/120 V to 12 V Adaptor Power adaptor (Optional)



## **Computer Requirements**

- Linux Ubuntu 20.04 (LTS) (recommended)
- CPU: Core-i3 5th generation or higher with Virtualization ON (if supported)
- RAM: 4GB or higher
- ROM: 120GB or higher
- Secure boot: Disabled (if available)



## **FPGA Requirements**

■ Bit file for the EVK Mother Board (PTP\_1\_8\_44\_hw\_1\_0\_14\_licensed.bit)



### Software Requirements

- Linux software package for the Lattice ORAN V1.1 solution stack (ltcPTPEmbeddedSW-x.x-xx.deb).
- Lattice Radiant Software 3.2 or later to flash the firmware.
- Lattice Propel Builder v2022.1



# Lattice ORAN Timing and Synchronization Kit



## Powering the Boards and Observing the Demo Program

- Connect a shunt on jumper pins as shown below. The jumpers should be in the indicated configuration.
- Insert two SFP modules for 10G interface into the 10G ports (J16 and J17). And connect the fiber optics cables to the SFP modules.
- Make sure the power switch (SW2) on the mother board is switched to the 12V\_PCIe.
- Make sure the power switch (J5) on daughter board is switched to the 12V\_PCle.
- Connect the daughter board to the mother board through the FMC port. Make sure they are firmly connected.
- Connect the mother board PCIe edge connector, through PCIe cable, to the Linux PC PCIe card slot.
- Power on the Linux PC and the EVK shall be powered on.

Part	Description	Settings
J5 (Motherboard)	FTDI- UART or I <sup>2</sup> C selection	Default 1–2 UART, Short 2-3 for I <sup>2</sup> C
J7 (Motherboard)	FTDI- UART or I <sup>2</sup> C selection	Default 1–2 UART, Short 2-3 for I <sup>2</sup> C
J14 (Motherboard)	VCCIO selection for Bank 0	Default short 1-2 for VCCIO=3.3 V, short 2-3 for VCCIO=1.8 V
J19 (Motherboard)	PCle link selection	Default Short 2-4 for PCle X4, Short 1-2 for PCle X1
J13 (Daughterboard)	Clock selection for IN0 input of DPLL	Default 1–2



## Doing More with the Lattice ORAN Timing and Synchronization Kit

Check the Lattice website at www.latticesemi.com/oran-timing-synchronization-kit to download the full User's Guide, the full source code of the default demo, and other resources. You can use the Lattice Radiant software to develop and program your own demos.

#### Additional Terms and Conditions Applicable to Lattice Programming and Development Hardware

Lattice device programmers, programming cables, socket adapters, and other hardware sold for use in conjunction with Lattice software ("Programming Hardware") and Lattice evaluation boards and development kits sold for use in conjunction with evaluating Lattice products ("Development Hardware") are designed and intended for use solely with semiconductor components manufactured by Lattice Semiconductor Corporation. Programming and Development Hardware is warranted to meet Lattice specifications only for a period of ninety (90) days; in all other respects the terms and continons of sale of Programming and Development Hardware shall be Lattice's standard terms and conditions set forth in Lattice's Sales Order Acknowledgment. Additionally, Lattice specifications for Programming and Development Hardware limit their use to low-volume engineering applications only, and not for volume production use. The warranty for Programming and Development Hardware will not apply to any Programming or Development Hardware used in production, used with worn or improperly installed hardware, or used with incompatible systems or components.

#### **Technical Support**

www.latticesemi.com/support

Copyright © 2024 Lattice Semiconductor Corporation. Lattice Semiconductor, L (stylized) Lattice Semiconductor Corp., Lattice (design) are either registered trademarks or trademarks of Lattice Semiconductor Corporation in the United States and/or other countries. Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.