



Using ORCAstra on Windows 7

If you downloaded ORCAstra along with Lattice Diamond®, you may have trouble opening it on the Windows 7 operating system. If you do, try the following procedure:

1. From the Windows Start menu, choose **Lattice Diamond > Accessories**.
A menu of Diamond accessories is displayed.
2. Right-click **ORCAstra system Bus Control Center**.
3. From the pop-up menu, choose **Properties**.
4. In the ORCAstra system Bus Control Center Properties dialog box, click the **Compatibility** tab.
5. Under Privilege Level, near the bottom, select **Run this program as an administrator**.
6. Click **OK**.
7. Try starting ORCAstra from the Start menu. Choose **Lattice Diamond > Accessories > ORCAstra system Bus Control Center**.

For more information about ORCAstra, go to:

www.latticesemi.com/products/designsoftware/orcastra.cfm