




Crosslink-NX VIP Sensor Input Board

This document provides a brief introduction to the Crosslink-NX VIP Sensor Input Board. The board is pre-programmed to demonstrate the 4 to 1 Image Aggregation Demo





Check the Kit Contents

The Crosslink-NX VIP Sensor Input Board kit contains the following items:

- Crosslink-NX Sensor Input Board
- IMX258 camera sensors (4 sensors, mounted on board)
- Camera sensor support piece
- USB Cable for Programming via PC (USB-A to Mini-B)
- Quick Start Guide



Crosslink-NX VIP Sensor Input Board

2

Assembling the Demonstration Hardware

This board will only work when used as part of the Lattice Embedded Vision Development Kit (EVDK). It is designed to be pin compatible with the Crosslink VIP Input Bridge Board. Follow the steps below to prepare the hardware before applying power.

- Remove Crosslink VIP Input Bridge Board from EVDK, replace with Crosslink-NX VIP Sensor Input Board. Connectors J5 and J4 of the Crosslink-NX VIP Sensor Input Board connect to J10 and J11 of the ECP5 VIP Processor Board.
- Mount cameras to camera connectors (CN0, CN1, CN2, and CN4).
- Mount camera sensor support piece and stick camera backs to piece.

The assembled hardware will look like the picture below:





Run the Demonstration

- Apply power to the ECP5 VIP Processor Board using a 12 V adapter.
- Connect jumpers to the Crosslink and ECP boards as follows:

CrossLink Jumper Settings	
Jumper	Pins to Connect
J2	Open
J3	Open
_	All other headers should be kept open

ECP5 Jumper Settings	
Jumper	Default
J3	1-2, 5-6
J5	1-2
J6	1-2
J7	2-3
J9	1-2
J50	1-2
J51	1-2
J52	2-3
J53	1-2
J55	2-3
_	All other headers should be kept open



Crosslink-NX VIP Sensor Input Board

- Connect HDMI cable between HDMI VIP Output Board and monitor.
- The output of the 4 cameras will be observed on the monitor as a single video stream
- SW3 on Crosslink-NX resets the pattern, SW5 changes camera view.





Done!

Congratulations! You have successfully demonstrated the 4 to 1 Image Aggregation demo on the Crosslink-NX VIP Sensor Input Board. This demo is intended to show basic functionality of the kit as shipped. This kit can be reprogrammed and/or connected to additional hardware (available separately) to demonstrate a number of bridging solutions. To learn more about these solutions and download full documentation for this kit, including schematics for all the boards, visit the Lattice website at: www.latticesemi.com/evdkit.

Development with the Lattice Crosslink-NX FPGA is supported by the Lattice Radiant Software. You can learn more and download the latest version from the Lattice website at www.latticesemi. com/radiant.

Additional Terms and Conditions Applicable to Lattice Programming and Development Hardware

Lattice device programmers, programming cables, socket adapters, and other hardware sold for use in conjunction with Lattice software ("Programming Hardware") and Lattice evaluation boards and development kits sold for use in conjunction with evaluating Lattice products ("Development Hardware") are designed and intended for use solely with semiconductor components manufactured by Lattice Semiconductor Corporation. Programming and Development Hardware is warranted to meet Lattice specifications only for a period of ninety (90) days; in all other respects the terms and contiions of sale of Programming and Development Hardware shall be Lattice's standard terms and conditions set forth in Lattice's Sales Order Acknowledgment. Additionally, Lattice specifications for Programming and Development Hardware limit their use to low-volume engineering applications only, and not for volume production use. The warranty for Programming and Development Hardware will not apply to any Programming or Development Hardware used in production, used with worn or improperly installed hardware, or used with incompatible systems or components.

Technical Support

www.latticesemi.com

Copyright © 2019 Lattice Semiconductor Corporation. Lattice Semiconductor, L (stylized) Lattice Semiconductor Corp., Lattice (design), Lattice Diamond, ECP5 and CrossLink are either registered trademarks or trademarks of Lattice Semiconductor Corporation in the United States and/or other countries. Other product names used in this publication are for identification purposes only and may be trademarks of their respective companies.

QS050 Rev. 2 December 2019